

Mighty Sweep

2003-8

Operators, Maintenance and Parts Manual



GEFFS MANUAL PART NUMBER

B80008-2012

EFFECTIVE SERIAL NUMBER 120926

REVISED 9/20/2012

NOTE: IT IS THE RESPONSIBILITY OF THE CUSTOMER OR USER'S MANAGEMENT TO TRAIN, EDUCATE, AND SUPERVISE THE EMPLOYEE IN THE PROPER OPERATION AND MAINTENANCE OF THIS EQUIPMENT.

GEFFS MANUFACTURING, INC.

950 SOUTH MAIN STREET

POCATELLO, ID 83204

208-232-1100

888-447-2882

208-234-4724 FAX

GEFFS MANUFACTURING INC.

Introduction

READ THIS MANUAL **carefully** to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

THIS MANUAL INCORPORATES operation and maintenance information for the GEFFS Manufacturing, Inc. Mighty Sweep. It is a compilation of the best information available at the time of writing. Some information may be specific to options not on all machines. All information and specifications are subject to change without notice.

USE ONLY CORRECT REPLACEMENT PARTS AND FASTENERS. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing in the direction of forward travel.

WRITE SERIAL NUMBERS in the back page of Introduction Section. Accurately record all the numbers to help in tracing the machine should it be stolen. File the serial numbers in a secure place off the machine.

WARRANTY is provided as part of GEFFS Manufacturing Inc. support

program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate, which is in the Introduction Section.

This warranty provides the assurance that GEFFS Manufacturing, Inc. will back its products where defects appear within the warranty period. In some circumstances, GEFFS Manufacturing, Inc. also provides improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering the machine will result in such action.

An extended warranty program is also available through GEFFS Manufacturing, Inc.



WARNING: THE MODEL 2003-8 IS A PIECE OF CONSTRUCTION EQUIPMENT. IT IS NOT MANUFACTURED PRIMARILY FOR USE ON OPEN PUBLIC STREETS OR HIGHWAYS NOR IS IT TO BE CONSIDERED SUITABLE FOR USE AS A MOTOR VEHICLE TO BE OPERATED OR USED ON PUBLIC STREETS, ROADS OR HIGHWAYS BY ANYONE WITHOUT FIRST ASSURING THAT ALL APPLICABLE SAFETY REQUIREMENTS AND PRECAUTIONS REQUIRED BY LAW OF SUCH USE HAVE BEEN MET.

Contents

Warranty	Introduction
Contacting Manufacturer	Introduction
Serial Numbers	Introduction
Safety	Section 1
Descriptions	Section 2
Specifications	Section 3
Pre-start Checks	Section 4
Operating the Sweeper	Section 5
Shipping	Section 6
Maintenance	Section 7
Lubrication & Maintenance Charts	Section 8
Storage	Section 9
Trouble Shooting	Section 10
Parts List	Section 11
Schematics	Section 12

GEFFS MANUFACTURING, INC

ONE YEAR BROOM WARRANTY

GEFFS MANUFACTURING, INC.

ALL NEW MACHINES AND PARTS ARE GUARANTEED AGAINST DEFECTIVE WORKMANSHIP AND/OR MATERIALS FOR A PERIOD OF ONE YEAR (12) MONTHS FROM DATE OF DELIVERY. GEFFS MANUFACTURING, INC. HEREAFTER KNOWN AS "THE MANUFACTURER" ASSUMES RESPONSIBILITY AND MAKES WARRANTY WITH RESPECT TO ENGINES, ENGINE ACCESSORIES, TRANSMISSION, AXLES, TIRES, HYDRAULIC MOTORS, HYDRAULIC PUMPS, OR OTHER PURCHASED COMPONENTS BEYOND THE WARRANTY OF THE SUPPLIER OF SAME.

THIS WARRANTY WILL NOT APPLY TO STANDARD WEAR PARTS TO INCLUDE BUT NOT LIMITED TO:

- 1) BROOM WAFER BRISTLES
- 2) RUBBER PRODUCTS
- 3) HYDRAULIC HOSES
- 4) FILTERS: FUEL, ENGINE OIL, HYDRAULIC OIL, TRANSMISSION OIL, COOLING , CAB PRESSURIZER
- 5) FLUIDS: FUEL, ENGINE OIL, HYDRAULIC OIL, TRANSMISSION OIL, ANTIFREEZE
- 6) LIGHT BULBS, SEAL BEAMS, CLEARANCE LIGHT BULBS
- 7) PAINT CHIPPING
- 8) WEATHER CHECK ITEMS FROM STORAGE OUTDOORS
- 9) TIRES
- 10) GLASS

THIS WARRANTY FURTHER WILL NOT APPLY TO OWNER MAINTENANCE RESPONSIBILITY ITEMS:

- 1) LOOSE BOLTS AND NUTS
- 2) LEAKS DUE TO LOOSE HYDRAULIC FITTING AND HOSE CONNECTIONS
- 3) BEARINGS DUE TO LACK OF MAINTENANCE

THIS WARRANTY FURTHER WILL NOT APPLY TO A MACHINE, WHICH HAS BEEN REPAIRED BY ANYONE OTHER THAN AN AUTHORIZED GEFFS MANUFACTURING, INC. DISTRIBUTOR USING GENUINE GEFFS MANUFACTURING, INC. PARTS, IMPROPER INSTALLATION, NOR DOES THIS WARRANTY APPLY TO USED EQUIPMENT OR DAMAGE THAT RESULTS FROM ACCIDENTS, ALTERATIONS, MISUSE, ABUSE, NATURAL WEAR AND TEAR, MALICIOUS MISCHIEF, VANDALISM, RIOTS, WARS, OR ACTS OF GOD. THE MANUFACTURER'S OBLIGATION UNDER THIS WARRANTY IS LIMITED TO THE REPLACEMENT OF ANY PART(S) WHICH SHALL BE FOUND TO BE DEFECTIVE WITHIN TWELVE(12) MONTHS FROM THE DATE OF DELIVERY TO THE ORIGINAL PURCHASER. THE MANUFACTURER'S WARRANTY DOES NOT OBLIGATE THE MANUFACTURER TO BEAR ANY OTHER COSTS EXCEPTING THE FURNISHING OF REPLACEMENT PART(S) FOR THE DEFECTIVE PART(S) AND LABOR FOR INSTALLATION OF THE DEFECTIVE PART(S). ALL OTHER DAMAGES, INCLUDING, BUT NOT LIMITED TO, ANY LOSS OR DAMAGE RESULTING FROM THE USE, OR LOSS OF USE, OF ANY OF SAID PRODUCTS, ARE HEREBY EXPRESSLY WAIVED. NO REPRESENTATIVE OF THE MANUFACTURER IS AUTHORIZED TO CHANGE THIS WARRANTY IN ANY WAY, AND NO ATTEMPT TO REPAIR THE PRODUCTS OF THE MANUFACTURER BY ANY REPRESENTATIVE OF THE MANUFACTURER SHALL CHANGE OR EXTEND THIS WARRANTY IN ANY WAY. APPROVED PARTS TO BE SUBSTITUTED FOR THOSE PARTS FOUND TO BE DEFECTIVE ARE TO BE FURNISHED TO THE CUSTOMER BY THE MANUFACTURER, F.O.B. FACTORY FREE OF CHARGE. INSTALLATION OF SUCH PARTS IS TO BE MADE BY, AND AT THE EXPENSE OF, THE MANUFACTURER OR AUTHORIZED SUBCONTRACTOR DURING THE WARRANTY PERIOD, **UNLESS THE PURCHASER IS AUTHORIZED IN WRITING BY THE MANUFACTURER TO MAKE SUCH INSTALLATION AT THE MANUFACTURER'S EXPENSE. ANY PARTY REPLACING WARRANTY PARTS AND/OR SERVICES MUST COMPLETE THE CORRECTIVE ACTION & WARRANTY REQUEST FORM OR THE MANUFACTURER WILL NOT WARRANTY THE PART(S) AND/OR SERVICE.** PARTS CLAIMED TO BE DEFECTIVE, AND FOR WHICH FREE REPLACEMENT IS DESIRED, MUST BE RETURNED TO THE MANUFACTURER, F.O.B. POCATELLO, IDAHO OR TO SUCH OTHER PLACE AS THE MANUFACTURER MAY DESIGNATE FOR INSPECTION.

GEFFS MANUFACTURING, INC., 950 SOUTH MAIN ST, POCATELLO, ID 83204

THE ABOVE WARRANTY IS VALID ONLY IF THE SYSTEM HAS BEEN USED AND MAINTAINED IN ACCORDANCE WITH THE INSTRUCTIONS CONTAINED IN THE OWNERS MANUAL. **FAILURE TO KEEP DETAILED MAINTENANCE RECORDS COULD RESULT IN VOIDING MANUFACTURER'S WARRANTY.**

GEFFS MANUFACTURING, INC. RESERVES THE RIGHT TO CHANGE ITS DESIGN AT ANYTIME WITHOUT INCURRING OBLIGATION TO MAKE SUCH DESIGN CHANGES ON MACHINES PREVIOUSLY SOLD.

THE ABOVE WARRANTY IS GIVEN IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION, THE WARRANTY OF MERCHANTABILITY AND THE WARRANTY OF SUITABILITY FOR A PARTICULAR PURPOSE. IT IS EXPRESSLY AGREED THAT GEFFS MANUFACTURING, INC. ASSUMES NO LIABILITY FOR INCIDENTAL AND CONSEQUENTIAL DAMAGES ARISING OUT OF A BREACH OF THIS CONTRACT, INCLUDING ANY WARRANTIES ARISING THEREFROM, AND PURCHASER REMEDIES SHALL BE LIMITED TO THE REPAIR OR REPLACEMENT OF DEFECTIVE PART(S) AND LABOR FOR INSTALLATION AS DESCRIBED ABOVE.

**** MUST BE SIGNED TO BE VALID ****

JEFFERY L. MATKIN CEO/PRESIDENT

Serial Numbers:

Mighty Sweep # _____

Engine # _____

Rear Axle # _____

DESCRIPTION	PART NUMBER	PAGE
1 1/2" Male Pipe Plug	B81120	45
3/8" Fuel Hose	80442	19
5/16" Nylock Hex Nut	15086	35
5/16" Proof-Coil Chain	16172	13
8' Broom Core	B60428	17
8" Broom Cover	B60445	17
AC Compressor	B81904-1	43, 53
AC Dryer	B80989	43
AC Dryer Mount	B80990	43
AC Filter Frame	B60427	35
Access Cover	B51153	25
Access Cover Gasket	B51157	25
Access Cover Plate	B51442	35
Adapter, Housing, Bell	B80993	27
Adjustable Valve	B81116	45
Alternator, John Deere, 75 Amp	B81900-75	51
Assy, Arm, Pedal, Brake, Removable Pad	B60715-1	7
Assy, Blower, Fan	B80987-7	35, 43
Assy, Blower, Light, Cab	B60505	47
Assy, Blower, Pressurizer, Cab	B80979	47
Assy, Box, Control, Water, Tanks Holddown	B60616-1	45
Assy, Clean-out Cover/Broom Control	B60005	25
Assy, Filter, Cab Pressurizer	B60502	35, 47
Assy, Holder, Fuse	B80980	47
Assy, Hose, AC, AC Unit to Compressor, #10	B60577	43
Assy, Hose, AC, Compressor to Condensor, #8	B60578	43
Assy, Hose, Ac, Condenser to Dryer, #6	B60575	43
Assy, Hose, Ac, Dryer to AC Unit, #6	B60576	43
Assy, Mount, Hydr, Motor	B60407	3
Assy, Mount, Pad, Pedal, Brake	B60052	7
Assy, Seal, Air, Latch, Door	B60045	39, 41
Assy, Tie rod, Broom	B60054	3
Assy, Wire, Power	B60504	47
Assy, Wire, Switch to Fan	B60503	47
Bearing Cone	B81010	13
Bearing Cup	B81009	13
Belt, Serpentine, 91.5" x 1.121"	B81900-17	51
Blast Shield	B51438	15
Bolt, Brake Hose Retainer	B81929	5
Bolt, Brake, Caliper	B81928	9
Bolt, Elevator, 1/2-20 X 3/4, PL-FNSH	15149	47
Bolt, Eye, 3/8-16 x 5"	15077	7
Bracket, Filter, Cab Pressurizer	B51105	47
Brake Cylinder Kit	B81127D	11
Brake Drum	B81127E	11

Brake Hose Assembly LH	B80940-1	5
Brake Hose Assembly RH	B80939-1	5
Brake Line 1/4 X 6"	B60484	5
Brake Line 3/16 X 12"	B81934	5
Brake Line 3/16 x 20"	B81941	5
Brake Line 3/16 X 30"	B81935	5
Brake Line 3/16 X 40"	B81936	5
Brake Line 3/16 X 51"	B81937	5
Brake Line 3/16 X 60"	B81938	5
Brake Pads	B80870A-1	9
Brake Rod Weld	B60466	7
Bronze Bushing	B51864	3
Broom Bearing Support	B51174	15
Broom Core End Plate	B51092	17
Broom Cylinder Pin	B51488	15
Broom Decal Kit	B60489-12	55
Broom Drive Coupler Assembly	B60432	15
Broom Driveline Assembly	B60516	3
Broom Frame Weld	B60442	15
Broom Motor Support	B51173	15
Broom Rear Axle	B81127	3, 11,
Bumper Standoff	B51142	21
Bushing, 1/4 Female Inv-Flare x 5/16 Male	B81231	5
Bushing, 1/4 Male Inv-Flare x 3/16 Female Invert	B81291	5
Bushing, Lug, Steering	B50053	3
Cab Floor Weld	B60453	31
Cab Rear Brace	B51122	35
Cab Weld	B60451	35
Cable, Heater Control	B80987-2	35, 43
Cable, Park Brake, 88"	B81161	5
Caliper Hardware Kit	B80870C	9
Caliper Kit	B80870B	9
Cap Screw, 1 X 4"	15056	13
Cap Screw, 3/8 X 1"	15124	25
Cap Screw, 5/16 X 1/2"	15087	35
Cap Screw, 5/8 x 2 1/4" UNC Grade 5	15090	35
Cap Screw, 5/8 X 2" UNC Grade 5	15089	35
Cap, Horn, Steering, Wheel	B81018	31, 33
Cap, Nozzle, Spray	B81112	45
Carriage Bolt, 1/2 X 2"	15083	21
Carriage Bolt, 1/2 X 5 1/2"	15062	21
Clamp, Cushion, 1/2"	80316	7, 51
Clamp, Cushion, 1-1/2", Fuel Hose	81603	51
Clamp, Hose, 1/2"	B81106	19, 45
Clamp, Hose, 5/8"	81223	51
Clamp, T-bolt, 3"	82734	49

Clamp, T-bolt, 4"	82735	49
Clamp, T-bolt, 5"	82748	49
Clamp,TBG, U-bolt, 3"	B81774	49
Clip, Pin, Cylinder	B80995	15
Coil, 12 VDC, Duetsch, Broom On/Off	B81907-15	29
Coil, 12VDC, Duetsch, Up/Dn & Swing	B81907-14	29
Condenser	B80988	43
Console Cover Weld	B60450	31
Console Cover Weld for Tilt & Telescoping	B60527	33
Console Weld with Tack and Speed Tilt/Tel	B60526	33
Console Weld with Tack only	B60522	33
Console Weld with Tack only Tilt/Telescoping	B60525	33
Console, Sub, Assy	B80969	47
Control Panel Weld	B60391	31
Controller, Broom	B81964	31
Cooler Frame Weld	B60640	23
Core, Heater	B80987-5	35, 43
Coupler, 1/2" NPT	B81973	45
Cover, Latch, Door, Cab	B50010	39, 41
Cup & Cone Bearing	B81127G	11
Cushion, Tank, Rubber	B51207	19, 45
Cylinder Pin	B80994	13
Decal , BROOM SWITCH	B81198	55
Decal , CAUTION CRUSH ZONE	80455	55
Decal , DOOR LATCH	B81326	55
Decal , ISO 32 HYD OIL	80087	55
Decal , SMALL GEFFS LOGO	80545	55
Decal FUEL GAUGE	B81329	55
Decal, 2003-8KO	B80949	55
Decal, BROOM LARGE STRIPE	B80952	55
Decal, BROOM LIGHTS	B80945	55
Decal, CAUTION BRAKE FLUID	80318	55
Decal, DIESEL FUEL	80088	55
Decal, MIGHTY SWEEP	B80950	55
Decal, WARNING SEAT BELT	B80957	55
Decal, WARNING STRUCTURES	B80956	55
Diode, Brake	B81292	31
Display	B81960	33
Door Latch	B51840	23
Door Weather-stripping	16146	37
Driveline, Broom, Quick Disconnect	B81166	3
Elbow, Exhaust, 3" with 12" Leg- Modified	B51759	49
Elbow, Rubber, 4" to 3"	B81996	49
Elbow, Rubber, Intake, 3"	B80996	49
Engine Cover Weld	B60471	23
Engine, John Deere 4045TF285, 85 HP	B81900	49, 51, 53

Evaporator Core	B80987-6	35, 43
Filter Element, Spin-on	80286A	27
Filter, AC, Foam, 3" Interior	B80987-4	35, 43
Filter, Ac, Pre-Filter	B80992	35, 43
Filter, Air, Primary	B81900-16	51
Filter, Air, Secondary	B81900-15	51
Filter, Fuel, Final, Fuel/Water Separator	B81900-12	51
Filter, Fuel, Primary, Fuel/Water Separator	B81900-13	51
Filter, Hydraulic Transmission, Spin-on	B81955	27, 51
Filter, Oil	B81900-21	51
Filter, Return, SAE	80286	27
Fitting, 3/4" NPT X 1/2" Barbed	B81123	45
Fitting, 3/8" NPT X 1/2 Barbed	B81976	45
Fitting, 3/8" Tube Barb	80749	19
Fitting, Adapter, Brass, 3/8" npt x 1/4"npt	80739	19
Fitting, Brass 3/8" Flare X 1/4 npt	80734	19
Fitting, Brass, 5/16" tube barb X 3/8" flare	B82003	19
Fitting, Brass, Elbow, 3/8" Flare X 3/8" npt	81174	19
Fitting, Brass, Plug, Hex, 3/8 npt	B82002	19
Fitting, Cross, Nozzle, Spray	B81110	45
Fitting, Elbow, 1/2" MPT x 1/2" Barbed	B81118	45
Fitting, Elbow, 90 Degree, R-134a High port #8	B81926	43
Fitting, Elbow, Nozzle, Spray	B81108	45
Fitting, Elbow, Street, 3/4" NPT	B81121	45
Fitting, Hyd, Elbow, 12 JIC-20 O-ring	B81995	27
Fitting, Nipple, Close, 3/4" NPT	B81119	45
Fitting, Nipple,Reducing, 1/2" x 3/8" NPT	B81124	45
Fitting, Reducing, 3/4" x 1/2"	B81998	45
Fitting, TEE, 3/4" NPT	B81975	45
Fitting, TEE, Barb	B81107	45
Fitting, TEE, Nozzle, Spray	B81109	45
Fitting, Union, 3/16 Inv-flare	B81940	5
Flange Bearing, 1 1/4"	B81011	15
Flat Washer, 1/2	15054-SAE	21
Flat Washer, 5/8	15088	35
Floor Mat	B50011	33
Front Axle Pin	B60418	3
Front Axle Weld	B60419-1	3
Front Bumper	B51198	21
Front Bumper Mount	B51196	21
Front Bumper with Spare Tire Mount	B60554	21
Fuel Cap	B81024A	19,
Fuel Sending Unit	B81034	19
Fuel Tank Holddown	B60499	19
Fuel Tank Mount	B51215	19
Fuel Tank, New Style	B80009	19

Fuel Tank, Old Style	B81024	19,
Fuel, Diesel	80550	19
Fuse, 20 AMP, IN-LINE	B80963	35
Gasket, Brake Hose	B81930	5
Grease Cup	B80880	9
Handle, Inside	B80789	39, 41
Handle, Outside, Locking, Keyed	B80788	39, 41
Harness, Broom, Propulsion & Functions	B81959	31
Harness, Twelve Lead, With Fuse Box	B81992	35
Harness, Wiper, CCW to Park	B81102-3	35
Harness, Wiper, CW to Park	B81102-2	35
H-clevis, 3/8"	B81164	13
Heating and Air Conditioning Unit, R134A	B80987	35, 43
Hex Jam Nut, 3/4-16	B81287	3
Horn, 12 volt	B81026	33
Hose, 3/4", 6000 PSI, JIC Straight Swivels	B81942	27
Hose, Fuel, 5/16"	B82001	19
Hose, Heater, 5/8"	B81952	51
Hose, Hump, 3"	81278	49
	82731	49
Hose, Hump, Reducing, 4-1/2" to 4"		
Hose, Reducing, Insert, 4" to 3"	82732	49
Hub and Rotor	B81918	9
Hydraulic Cylinder, Lift	B80817	13, 27
Hydraulic Cylinder, Steering	B80816	3, 27
Hydraulic Cylinder, Swing	B80818	13, 27
Hydraulic Diffuser, SAE	82838	25
Hydraulic Motor	B81903	15
Hydraulic Motor, Broom Drive	B80815	27
Hydraulic Oil Cooler	80819	21
Hydraulic Propel Motor	B81897-3	27
Hydraulic Pump, Accessory, 28 GPM	B81898	27
Hydraulic Reservoir Assembly	B60393-1	25
Hydraulic Suction Strainer, SAE	82837	25
Hydrostatic Pump, Linde	B81896	27
Inner Cone Bearing	B80877	9
Inner Cup	B80878	9
Inner Oil Seal	B81127F	11
Insulation, Cab, Floor,	B81994	35
Isolator, Rubber, Engine	B80824	51
Jam Nut, 1 3/4-12	15069	13
Joystick, Broom Function	B81798	33
Joystick, Broom Function	B81798	31
Joystick, Broom Fwd/Rev, Throttle	B81906	31, 33
Knob, Control	B80967	47
Knob, Potentiometer	B81962-7	31
Latch, Filter Pan	B80968	47

Left Hand Brake Cylinder	B81127C	11
Left Hand Caliper Assembly	B80871-1	9
Left Hand Door	B60388	41
Left Hand Engine Door and Frame Weld	B60642	23
Left Hand Rotor Latch	B81369	39, 41
Left Hand Tie Rod End	B81006	3
Left-hand Broom Motor Arm	B60440	15
Lever, Park Brake	B81160	5
Light, Dome, Small	B80978	33, 47
Light, Front, Turn Signal	B80999	33
Light, Head, Halogen	B81000	33
Light, Head, LED	B82012	33
Light, Park Brake, Indicator, Red	B81130	33
Light, Rear, Brake/Turn/Tail	B80998	23, 33
Light, Rear, Brake/turn/Tail, LED	B80904	33
Light, Strobe	80268	33, 35
Light, Work	80198	33
Lighter, Accessory Socket	B81901	31, 33
Limit Straps	B51056	15
Liner, Cab, Front	B50012	33
Liner, Cab, Head	B50014	33
Liner, Cab, Rear	B50013	33
Liner, Compartment	B50015	33
Louver, Pressurizer	B80965	47
Lower Ball Joint	B80873-2	9
Lug Nut, 1/2-20	B81048	3, 9, 11, 21
Manifold	B81907-1	29
Manifold, Broom Control	B81907	25, 27, 29
Master Cylinder	B81007	5
Moisture & Sight Glass	B80985	43
Molding, Door, Broom, Lower	16147LBD	39, 41
Molding, Door, Broom, Upper	16147UBD	39, 41
Motor, Wiper, 2 Speed	B81102A	35
Motor, Wiper, Front and Rear	B81102	35
Muffler	B81900-19	51
Nut, Hex, 1/4-20, GR 8, Y-Zn-PLD	15003	15, 39, 41
Nut, Hex, 20mm – 1.5, LH Thread	15316	3
Nut, Hex, 22 mm – 1.5, RH Thread	15317	3
Nut, Hex, 3/4-10, Y-ZN-PLD	15071	15
Nut, Hex, 3/8-16, GR 8, Y-Zn-PLD	15065	15, 17, 39, 41
Nut, hex, 5/16-18, Y-ZN-PLD	15034	15
Nut, Hex, Nylock, 3/8-16 GR 8, Y-Zn-PLD	15022	7
Nut, Hex, Nylock, 1/4-20 GR 8 Y-Zn-PLD	15085	47
Nut, Jam, Steer, Cylinder, Tie Rod, 3/4"-16, LH	B81827	3
Nylock Hex Nut, 1/2	15066	21
Nylock Hex Nut, 5/8"	15024	35

Nylon Bushing for Brake Pedal	B51126	7
Nylon Hex Nut, 1"	15081	13
Nylon Nut (Included with #12, 13 & 14)	B81195	45
Oil Seal	B80874	9
Oil Seal	B81008	13
Oil, Hydraulic, ISO 32 10 wt	80473	25
Outer Cone Bearing	B80875	9
Outer Cup	B80876	9
Outer Oil Seal	B81127H	11
Pad, Pedal, Brake	B80006	7
Pan, Filter	B81162	47
Pedal, Foot, Throttle, Optional	B81963	31
Pin, Clevis, 5/16 x 3/4, pl-fnsh	80251	3
Pin, Size 12	B81913	31
Pin, Size 16	B81911	31
Pin, Striker, Latch	B81371	39, 41
Pipe Plug, 3/4"	80275	25
Piston, Single Pilot	B81907-21	29
Plug, Expansion	B81907-4	29
Plug, Hex, O-ring, 32	B81993	27
Plug, SAE-02	B81907-2	29
Plug, SAE-04	B81907-24	29
Plug, SAE-06	B81907-13	29
Plug, SAE-08	B81907-23	29
Plunger, Door Holder	B81021	39, 41
Poly & Steel Brush Assy (25 Poly, 21 Steel)	B60553	17
Poly Brush Assembly	B60476	17
Poly Tank 150 gallons	B81125	45
Potentiometer, Float	B81962-6	31
Pre-Cleaner, Turbo II, With Clamp	B80902	49
Pressure Filler Breather	80838	25, 27
Pressurizer, Cab	B60506	47
Pressurizing Blower	B60605	35
R.O.P.S. Roll Bar	B60426	35
Radio, AM/FM, Clock, Roof Mount	B81990	33
Rear Axle Assembly	B81127I	11
Rear Axle U-bolt	B81138	3
Rear Brake Shoe	B81127A	11
Rear Bumper	B51198	21
Rear Lug Stud	B81127J	11
Receptacle, Connector, Shell Size 24	B81916	31
Relay, Back-up Alarm	81214	33
Relay, Flasher, Turn Signal	80197-1	33
Relay, Horn	B81027	33
Right Hand Brake Cylinder	B81127B	11
Right Hand Caliper Assembly	B80870-1	9

Right Hand Door	B60387	39
Right Hand Engine Door and Frame Weld	B60641	23
Right Hand Rotor Latch	B81370	39, 41
Right Hand Tie Rod End	B81005	3
Right-hand Broom Arm	B60439	15
Roll Bar Mount	B51099	35
Rotating Beacon	B81029	33
Rubber Bumper	B81167	23
Rubber Spacer	B80826	15,
Screen Weld	B60494	23
Screw, Cap, Hex, 1/2-13 x 2, GR 8, Y-Zn-PLD	15061	5, 21
Screw, Cap, Hex, 1/2-13 x 4-1/2, GR 8, Y-Zn	15084	5
Screw, Cap, Hex, 1/4-20 x 1 3/4, GR 8 Y-Zn-PLD	15158	39, 41
Screw, Cap, Hex, 1/4-20 x 1, GR 8, Y-Zn-PLD	15049	39, 41
Screw, cap, hex, 1/4-20 x 1-1/4, Y-ZN-PLD	15002	15
Screw, Cap, Hex, 3/4-10 x 4", GR 8m Y-ZN	15070	15
Screw, Cap, Hex, 3/8-16 x 1", GR8, Y-Zn-PLD	15275	17
Screw, Cap, Hex, 3/8-16 X 1-1/4 GR 8, Y-Zn	15123	7, 15
Screw, Cap, Hex, 3/8-16 X 2", Gr 8, Y-ZN_PL	15228	15
Screw, Cap, Hex, 3/8-16 x 3, GR 8, Y-Zn-PLD	15152	39, 41
Screw, cap, hex, 5/16-18 x 1, Y-ZN-PLD	15243	15
Screw, Dust Shield Retaining	B81927	9
Screw, Hex, Wsh, TEK, 1/4 X 1, ZN-PLD	15278	47
Screw, Mach, 10-32 x 1/2, FLH, PHH, Zn-PLD	15260	39, 41
Seat Belt	B81017	31
Seat Stand	B60425	31
Seat with Arm Rest	80020	31
Seat, Filter, Cab Pressurizer	B51482	47
Sender, Fuel, Reed Style 10"	B81991	19
Shield, Brake	B80873-1	9
Sight Gage with thermometer	B81902	25
Slotted Hex Nut, 1-14	15079	3
Socket, Door Holder	B81022	39, 41
Spacer	B51123	13
Spacer	B80937	17
Spacer, Coil, Size 8	B81907-22	29
Spacer, Door, Broom, Lower	B50008	39, 41
Spindle Nut Kit	B80879	9
Spindle, Left Hand	B81923	9
Spindle, Right Hand	B81924	9
Spray Bracket	B51161	45
Stainer, TEE, Line	B81111	45
Starter, John Deere, 4045TF285, 85 HP	B81900-11	51
Stay, Pin, Axle, Front	B51172	3
Steering Column	B81012	31
Steering Column with Tilt & Telescoping	B80959	31

Steering Cylinder Mount	B60422	3
Steering Orbital Motor	B81899	27
Steering Wheel	80022	31
Steering Wheel Nut	80270	31
Strainer, 100 Mesh, Spray, Tip	B81113	45
Swing Arm Access Plate	B51188	35
Swing Arm Frame Weld	B60436	13
Swing Frame Spacer	B51136	13
Switch , Turn Signal	80195	31
Switch, Binary, Low Pressure	B80986	43
Switch, Door, Jam	B82000	33
Switch, Fan Speed, Control	B80987-3	35, 43
Switch, Ignition, Keyed	B81031	31
Switch, Light, Head	B81032	31, 33
Switch, Park, Brake	B81086	31
Switch, Rheostat	B80966	47
Switch, Stop Light	B81025	33,
Switch, Toggle, SPST	81535	31, 47
Switch, Wiper, Variable Speed	B81103	33
Switch, Wiper, Variable Speed	B81103-1	31, 33
Switch,Wiper	B81131	33
Tee, 1/8" NPTF x 1/4 Female Inverted Flare	B81158	5
Tee, 3/16 Female Inverted Flare	B81156	5
Template SERIAL NUMBER & MODEL	80461	55
Template, CONSOLE RIGHTHAND	B50029	55
Tie Rod End	B81016	3
Tilt Column Mount Weld	B60581	33
Tip, Spray, Brass	B81114	45
Tire, LT225-75R16	B81014	3
Top Tank Holddown	B60456	45
Transducer, Pressure, 3626 PSI	B81962-3	27
Transducer, Pressure, 580 PSI	B81962-1	27
Transducer, Pressure, 7250 PSI	B81962-2	27
Transducer, Temperature	B81962-4	25
Tube, Exhaust, 3" X 44"	B51254	49
Tube, Exhaust, 3" X 7"	B51753	49
Tube, Overflow, 5/16"	B82008	51
Tubing, Clear, 1/2"	B81117	45
U-joint Cap & Bolt Assembly	81134	3
Universal Joint	80159	3
Upper Ball Joint	B80873-3	9
Valve, Boiler, 3/4"	B81999	45
Valve, Cartridge, Tandem Spool	B81907-3	29
Valve, check, 30 psi	B81907-12	29
Valve, Check, 5 psi	B81907-16	29
Valve, Flow Control, 2.5 GPM	B81907-10	29

Valve, Flow Control, Pressure Compensated	B81907-18	29
Valve, Heater, Control	B80987-1	35, 43
Valve, Piston, Dual	B81907-5	29
Valve, Priority	B81907-7	29
Valve, Proportional, Relief, Float	B81907-20	29
Valve, Push-Pull, Steering, Cutoff, Tow Package	B81925	27
Valve, Relief, 250-1800 psi	B81907-9	29
Valve, Relief, 250-3000 psi	B81907-6	29
Valve, Solenoid, 3 Position, 4 way, Open Center	B81907-11	29
Valve, Solenoid, Poppet	B81907-8	29
Valve, Union	B81122	45
Wafer, Poly	B80938	17
Wafer, Steel	B81128	17
Washer Bulkhead Fitting, Front and Rear	B81192	35
Washer Hose Kit, Front and Rear	B81193	35
Washer Nozzle, Front and Rear	B81191	35
Washer, Flat, SAE, 1/4, GR9, Y-Zn-PLD	15202-SAE	39, 41
Washer, Flat, SAE, 1", GR 8, Y-ZN-PLD	15080-SAE	15
Washer, Flat, SAE, 3/8, GR 8, Y-Zn-PLD	15131-SAE	15, 17, 39, 41
Washer, Flat, USS, 1/4, GR8, Y-Zn-PLD	15165	15, 47
Washer, Flat, USS, 5/16", Y-ZN-PLD	15057	15
Washer, Lock, 1/4, GR 8, Y-Zn-PLD	15004	15, 39, 41
Washer, Lock, 3/8, GR 8, Y-Zn-PLD	15064	15, 17, 39, 41
Washer, Lock, 5/16", Y-ZN-PLD	15035	15
Washer, Neoprene Bonded, 3/8" ID, 3/4" OD	80823	25
Washer, Windshield, Dual Pump, 4 liter	B81989	35
Washer, Windshield, Front only, 4 liter	B81099	35
Water Pump	B81104	45
Weather Strip, Glass,	16147	37,
Wheel Stud	B80869A	9
Wheel, 16"	B81943	3, 9,
Window, Glass, Door, Lower, Tinted, Safety	B81367	37, 39, 41
Window, Glass, Door, Upper, Tinted, Safety	B81368	37, 39, 41
Window, Glass, Front, Tinted, Safety	B80833	37
Window, Glass, Left-hand, Tinted, Safety	B80837	37
Window, Glass, Rear, Tinted, Safety	B80834	37
Window, Glass, Right-hand, Tinted, Safety	B80836	37
Wiper Arm, Front and Rear	B81100	35
Wiper Blade, Front and Rear	B81101	35
Zerk, 45 degree, 1/4-28	15196	15
Zerk, Grease, 1/4-28, Short-straight	15000	7

Section 1

Safety

This section provides information about general and specific safety practices and procedures. Always follow good safety practices and procedures. Carefully read all safety messages in this manual and on your machine safety signs.

Personnel must take time to read this section thoroughly. If uncertain about any information represented, contact your supervisor or GEFFS Manufacturing, Inc. at 1-888-447-2882 for clarification before operation.

If you are not experienced with operation of this equipment, make certain you receive instruction from your supervisor before beginning work. Operate the sweeper in a clear open area to familiarize yourself with the controls and operating characteristics.

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual be alert to the potential for personal injury.



Follow recommended precautions and safe operating practices.

UNDERSTAND SIGNAL WORDS

A signal word - DANGER, WARNING, or CAUTION - is used with the safety-alert symbol.

DANGER indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury.

WARNING indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury, and includes hazards that are exposed when guards are removed.

CAUTION indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs.

WARNING or CAUTION also calls attention to safety messages in this manual.

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.

WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



WARNING: FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from GEFFS Manufacturing, Inc.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instructions.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact GEFFS Manufacturing, Inc.

WARNING: DRIVING THE SELF-PROPELLED SWEEPER

Operate the self-propelled sweeper only when operator is seated, seat belt securely fastened and all guards are in their correct position.

Before driving away, check immediate vicinity of machine for bystanders. Use the horn as a warning immediately before driving away.

Riders are subject to injury such as being thrown off the machine. Riders also obstruct the operator's view resulting in the machine being operated in an unsafe manner.

Manually check all primary controls for proper function prior to each prior of operation or use.

Before dismounting be certain that the parking brake is set and the transmission is in neutral.

WARNING: USE SAFETY LIGHTS AND DEVICES

Slow moving self-propelled equipment and attachments can create a hazard when driven on public roads. They are difficult to see, especially at night. Avoid personal injury or death resulting from collision with a vehicle.

Whenever driving on public roads, use flashing warning lights and turn signal according to local regulation. To increase visibility, use the lights and devices provided with your machine.

Keep safety items in good condition. Replace missing and damaged items.

WARNING: WORK IN VENTILATED AREA

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.

WORK IN CLEAN AREA

Before starting a job:

Clean work area and machine.
Make sure you have all necessary tools to do your job.
Have the right parts on hand.
Read all instructions thoroughly. Do not attempt shortcuts.

ILLUMINATE WORK AREA SAFELY

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure a wire cage encloses the bulb. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.

USING HIGH-PRESSURE WASHERS

IMPORTANT: Directing pressurized water at electronic/electrical components or connectors, bearings and hydraulic seals, fuel injection pumps or other sensitive parts and components may cause product malfunctions. Reduce pressure, and spray at a 45° or 90° angle.



WARNING: USE PROPER LIFTING EQUIPMENT

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.

USE PROPER TOOLS

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. **DO NOT** use U.S. measurements tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting GEFMS Manufacturing, Inc. specifications.

USING SPECIAL TOOLS

Faulty or broken tools can result in serious injury. When constructing tools, use proper, quality materials and good workmanship.

Do not weld tools unless you have the proper equipment and experience to perform the job.

WARNING: SUPPORT MACHINE PROPERLY

Always lower the attachment to the ground before you work on the machine. If you must work on the lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.

WARNING: HANDLE FLUIDS SAFELY - AVOID FIRES

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Fill fuel tank outdoors.

Make sure machine is clean of trash, grease and debris. Always clean up spilled fuel.

Do not store oily rags. They can ignite and burn spontaneously.

Overfilling may cause spillage due to fuel expansion. Clean up any spilt fuel.

Transport and store fuel only in an approved manner.

Caution: PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Do not change a battery when it is frozen, it may explode. Warm the battery to 16°C (60°F).

 **Caution: PREVENT ACID BURNS**

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed in eyes.

Avoid the hazard by:

1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Using proper jump-start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid on skin.
3. Flush your eyes with water for 15-30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
 2. Drink large amounts of water or milk, but do not exceed 2 quarts (2 L).
 3. Get medical attention immediately.
-

 **Caution: AVOID HEATING NEAR PRESSURIZED FLUID LINES**

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.



Caution: AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high-pressure fluid.

If an accident occurs, see a doctor immediately. Any fluid injected in the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source.



Caution: HANDLE CHEMICAL PRODUCTS SAFELY

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with GEFFS Manufacturing, Inc. equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products, physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

Contact GEFFS Manufacturing, Inc. for MSDS's on chemical products used with GEFFS Manufacturing, Inc. equipment.



Caution: REMOVE PAINT BEFORE WELDING OR HEATING

Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well-ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating.

If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.

If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

WARNING: AVOID CONTACT WITH MOVING PARTS

Keep hands, feet and clothing away from power driven parts. Never clean, lubricate or adjust machine when it is running.

PRACTICE SAFE MAINTENANCE

Understand service procedure before doing work.

Never lubricate, service or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil or debris.

Disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

Caution: SERVICE COOLING SYSTEM SAFELY

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to the first stop then relieve the pressure before removing completely.

DISPOSE OF WASTE PROPERLY

Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with GEFFS Manufacturing, Inc. include such items as oil, fuel, coolant, filters, and batteries.

Use leak proof containers when draining fluids. Do not use food or beverage containers that may mislead someone in drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center.

Notes

Section 2

Descriptions

A. General

The GEFFS Manufacturing, Inc. Mighty Sweep 2003-8 self-propelled broom sweeper has been designed for the removal of materials from hard surfaced areas. The material is generally moved to the left or right of the sweeping pattern with no provisions for picking up the material.

The base machine consists of:

Chassis	Engine
Hydrostatic Transmission Drive System	Brakes
Tires and Wheels	Steering System
Broom	Hydraulic System
Roll Over Protective Structure (R.O.P.S.)	Electrical System
Cab	

The machine serial number location is on the left side just in front of the engine compartment.

Model 2003-8 indicates that this machine is a model built in 2003 with an 8-foot broom width.

Serial number example (031201)

03 - represents the year the machine was built.

12 - represents the month the machine was built.

01 - represents the number of the machine that was manufactured.



WARNING: Always keep hands, feet and clothing away from power driven parts. Never clean, lubricate or adjust machine when it is running.

Keep your machine in proper working condition.

Operate broom sweeper only when all guards are in their correct position.

B. Chassis

The frame is an all welded 1/4", 3/8" and 1/2" steel chassis. Gussets are provided at all stress points, cross-members are included, as necessary, as are mounting provisions for all required components and accessories.

Chassis includes mounting provisions for a solid rear axle and drive motor mount plate, as well as the oscillating front axle.

Chassis includes mounting provisions for certified R.O.P.S., cab that is attached with specified hardware. R.O.P.S. can be removed and replaced without affecting certification.

C. Engine

Power is provided by a 275 C.I.D. 4 cylinder liquid cooled John Deerediesel engine Model 4045TF285 rated at 85 bhp at 2400 rpm. Engine includes 12-volt DC electrical system, starter and 75-amp alternator.

Clean air is supplied through a heavy-duty Donaldson type dry air cleaner, includes a primary element, a safety element and an external pre-cleaner. Air cleaner housing includes a vacuator valve and a restriction (service) indicator.

The engine oil system is pressurized and regulated with a spin-on filter and filter by-pass.

The engine is mounted on six (4) engine isolators.

Engine exhaust is routed vertically above the engine through a muffler.

Engine fuel system includes a 32-gallon plastic fuel reservoir, dual spin-on pressure filters with water separator and drain.

The engine throttle controls the RPM, which controls the pumps fluid flow. The engine RPM will effect the travel speed and the broom rotation RPM.



WARNING: Always work in a ventilated area. Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension. If you do not have an exhaust pipe extension, open the doors and get outside air into the area.

D. Hydrostatic Transmission Drive

The machine is driven by an Linde infinitely variable hydrostatic transmission consisting of a variable displacement pump and a fixed displacement motor. The hydrostatic transmission will develop 6000 psi. The operator controls consist of one (1) joystick which control the stroke of the variable piston displacement pump. Control of the variable piston displacement pump is the key to controlling vehicle speed. The pump transmits prime mover horsepower when the operator moves the joystick either forward or reverse. This in turn, at any given input speed, produces a certain flow from the pump. This flow rate is transferred through high-pressure lines to the motor. The ratio of the volume of flow from the pump to the fixed displacement motor will determine the speed of the motor output shaft. Moving the joystick in reverse allows the motor to reverse direction and propel the broom in reverse.

The operator presence switch prevents the broom from moving when it is in the off position. The switch must be in the on position and the brake pedal depressed before the pump will allow flow to the motor.

The machine is capable to travel speeds of 0-10 mph and 0-20 mph by switching the toggle switch on the side console.

Speed of the output shaft is controlled by adjusting the displacement flow of the transmission and the engine RPM. Load (working pressure) is determined by the external conditions (i.e. grade, ground conditions, etc.) and this establishes the demand on the system.

Pump and motor are contained in separate housings. All valves required are included in either the pump or motor assemblies.

Oil is drawn from the reservoir through the 10-micron suction filter through the pump and motor, and back to the reservoir.

The Linde Motor drives a short driveline to a Dana Model 44 rigid semi-float rear axle. Rear axle includes drum brakes and parking brake.



WARNING: Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic lines. If accident occurs, see a doctor immediately.

Always keep hands, feet and loose clothing away from power driven parts. Never clean, lubricate or adjust machine when it is running.

Keep your machine in proper working condition.

E. Brakes

Mighty Sweep includes a 4 wheel self-adjusting, automotive system, which includes front disc and rear drum brakes. Dual master cylinder provides separate circuit for front and rear. Rear drums include parking brake mechanism connected to adjustable pull lever at operator's station.

F. Tires and Wheels

Machine includes automotive type 5 bolt 5.5-inch diameter bolt circle, 16-inch diameter x 6-inch wide front and rear wheels. Tires are LT225-75R16 tire 6 ply, highway tread design. Tire Pressure is 50 psi. Check the lug nuts daily, torque to 100 foot-pounds.

G. Steering System

Power steering is fully fluid linked, consisting of a manually operated directional control valve and a steering cylinder attached to the left hand steering arm. Fluid pressure is supplied from the priority flow control valve in the valve manifold to the steering control valve and is there directed to the appropriate side of the steering cylinder. Steering control orbital valve is a non-load reaction design, which holds the axle position whenever the operator releases the steering wheel.

H. Broom Assembly

Broom consists of a steel core with a shaft extending from one end for bearing support and a drive plate attached to the other end. The core is driven by a direct single drive, high torque hydraulic motor containing a four (4) square pin drive hub and taper alignment shaft. The design allows for the motor to be enclosed inside the drive end of the core. The 8 foot core will accept approximately 46 standard 10" x 32" poly or steel wafers and spacers as required.

The broom is mounted on an arm, which is attached to the frame with a tapered roller bearing spindle assembly. This broom arm can swing, using a hydraulic cylinder to a maximum of 45° right or left.

The broom can also be raised or lowered hydraulically with a single lift cylinder. Both swing and lift control valves are manual and located at operator's station. The broom hydraulic system features an adjustable broom counterbalance circuit, which is adjustable from the

operator's station. With the control knob the operator adjusts the pressure in the lift cylinder, which increases or decreases the broom pressure on the ground and therefore the sweeping pattern width. This circuit only functions when the broom lift control switch is in the "ON" position. Once the desired sweeping pattern is obtained the control knob will stay in this position and the system will maintain this preset pattern regardless of the variations in the road surface or broom wear. The broom arm design also allows for the broom to oscillate about an axis along the longitudinal centerline of the sweeper to permit full contact of the brush left or right on uneven surfaces.

The broom wafers are covered by a 16 gauge steel 160° cover, and a rubber blast shield which is suspended down in front of the broom to prevent debris from being thrown vertically and into the front of the sweeper.



WARNING: Always keep hands, feet and loose clothing away from power driven parts. Never clean, lubricate or adjust machine when it is running.

Keep your machine in proper working condition.

Operate broom sweeper only when all guards are in their correct position.

I. Hydraulic System

Hydraulic oil is contained in the 30 gallon pressurized "L" shape reservoir. Total system capacity is 38 gallons. The reservoir is pressurized to 10 psi by fluid expansion and includes two cleanout covers, one at the front and the other on the top. It includes a baffle that separating inlet and outlet ports. There is a fluid level gauge that can be seen inside the engine compartment on the left side.

All hydraulic fluid returns to the reservoir at the rear and travels forward around the baffle to the suction ports. The auxiliary circuit returns all fluid through a hydraulic oil diffuser and draws all hydraulic fluid through a 100 mesh suction strainer.

The reservoir has two separate suction lines. One line for hydrostatic drive system, the other supplies the auxiliary hydraulic functions. The hydrostatic system draws fluid from the front of the reservoir through a 100 mesh suction strainer. The hydraulic transmission offers variable control of speed and direction. The operator has complete control of the sweeper with the joystick for starting and stopping, in forward or reverse motion.

Speed of the output shaft is controlled by adjusting the displacement flow of the transmission and the engine RPM. Load (working pressure) is determined by the external conditions (i.e. grade, ground conditions, etc.) and this establishes the demand (5000 psi max) on the system.

Pump and motor are contained in separate housings. All valves required are included in either the pump or motor assemblies. Fluid supplied by the charge pump is circulated in a closed loop through the pump and motor. A certain amount of internal leakage naturally occurs in the pump and motor. This leakage is used to lubricate and cool the pump and motor prior to returning to the oil reservoir through the case drain hoses.

The auxiliary hydraulic circuit draws fluid through a 100 mesh suction strainer located inside the reservoir. Fluid then enters the accessory pump, which is a 27 GPM gear type pump when the engine is running at 2400 RPM.

All fluid from the auxiliary pump run through the valve manifold system. Here the broom steering is given 2.5 GPM dedicated flow. The remainder of the flow, approximately 1.5 GPM, supplies fluid for control of the swing cylinder and broom lift cylinder. Fluid to the steering orbital motor (open center) is returned to the manifold prior to returning to the hydraulic tank. Fluids from the Swing and Lift cylinders also return to the manifold prior to returning to the hydraulic tank.

The hydraulic broom counterbalance circuit functions when the lift control switch is turned "ON", allowing it to float during the sweeping operation. The operator remotely adjusts a relief valve that controls the pressure to the broom lift cylinder and maintains the broom pressure on the surface being swept.

The excess flow of fluid from the accessory pump will be variable depending on engine RPM. This flow routes directly to the broom drive motor which has a fixed displacement. The broom rotation rpm therefore is a variable speed and a function of the engine RPM to a maximum of 23 GPM with approximately 260 RPM for the broom.

An ON-OFF valve provides the broom operation. The valve diverts oil to the return line when the broom motor is off. Closing the valve blocks the oil path to the return line, forcing the oil to go through the broom motor.

All of the fluids in the auxiliary circuit returns to the reservoir through a 10-micron return filter and an oil cooler with a pressure bypass. Fluid returns to the rear of the reservoir through an internal oil diffuser accessible by removal of the rear clean out port cover. As in all hydraulic systems reliability depends upon clean and cool hydraulic oil.

J. Roll Over Protection Structure (R.O.P.S)

The machine is provided with a certified R.O.P.S roll bar that is attached to the frame with specified hardware. R.O.P.S. can be removed and replaced without affecting certification.



DANGER: Never remove the R.O.P.S. roll bar from the machine!

Never operate the machine if the R.O.P.S roll bar is damaged or if it has been removed!

Always replace a damaged R.O.P.S roll bar with a certified roll bar! Never try to repair or straighten the R.O.P.S. roll bar!

Always use the proper Grade of Hardware.

K. Electrical System

The machine is provided with a 12-volt DC electrical system that includes a 75-amp alternator (minimum). A larger alternators are available as an option.

L. Cab

The cab is pressurized with filtered fresh outside air. It includes the pressurizing system, air conditioning and heating. . The glass is tempered and tinted. A defrost kit, window wiper and window washer is optional (front, rear, or both windows). The steering column has a choice of fixed or telescoping/tilt. The seat is cushioned with a seat belt. Under the seat is a storage area. The Sauer Danfoss display is utilized for all system monitoring. Sound insulation is included with the cab to reduce the noise inside. The cab doors can be locked to prevent theft.

M. 2-Speed

The 2-speed operation is a standard that will allow the machine to operate in low gear or high gear. The machine will operate and sweep in either gear. The hydrostatic pump is electrically controlled to allow either low speed 0-10 mph or high speed 0-20 mph travel. The switch is located to the right of the operator near the forward/neutral/reverse joystick.



DANGER: Death or injury may occur if the below instructions are not followed.

- 1. The changing of speeds should only be done when vehicle is stopped.**
- 2. Do not try to shift while machine is in motion!**

Section 3

Specifications

A. General

Diesel Engine –

85 hp, 275CID
Tier III compliant
4-cylinder
Water cooled, thermostat range 173° - 196°
12-volt DC, 75-amp minimum

Drive Train –

Heavy-duty Linde hydrostatic transmission
Variable speed, 6000-psi max system pressure
0 – 20 MPH max
2-speed electrical shift

Front Steering Axle –

Automotive type tube with spindles
Hydraulic disc brakes
18° oscillation

Rear Drive Axle -

Dana heavy-duty truck type, rigid
Semi-float differential
Hydraulic drum brakes

Tires, Wheels and Pressures –

Wheels, 16” Steel, 5 hole
Tires, LT225/75 R16, 6-ply
Tire pressure – 50 psi
Lug nut torque – 100 foot-pounds

Auxiliary Pump –

27-GPM
2.5-GPM priority steering
1500-psi system pressure

Broom Wafer –

Poly, 10 X 32
Steel wire, 10 X 32

Broom RPM –

260 rpm max

Electrical system –

12 volts DC

Lighting system –

Tail/stop lights, 12 volt DC
Strobe light, 12 volt DC
Work lights, 12 volt DC

Hydraulic Filters –

Transmission suction 100 mesh suction screen, 10 micron filter
Return, 10-micron
Auxiliary suction, 100-mesh

Water Spray System –

Tank capacity, 150 gallons, Weight full – 1245 Pounds
Pump, 12 volt DC
Pump flow, 1.5 GPM
Pump pressure, 60 psi
Fluid strainer, 80-mesh
Nozzle filtration, 100-mesh

Air Conditioning –

18,000 BTU/HR

Heating –

28,600 BTU/HR

Pressure Fan –

800 CFM with filter

Windshield Washers –

Front, Standard
Rear, Optional

B. Capacities

Fuel tank - - - - - 32 gallons
233 Pounds of Fuel

Hydraulic tank - - - - - 30 gallons
219 pounds of hydraulic oil

Total hydraulic system - - - - - 38 gallons
277 Pounds of Hydraulic Fluid

Engine capacities - - - - - see engine manual

Coolant - - - - - 5 gallons (50/50 mix)

Rear axle capacity - - - - - 1 3/4 quarts

Brake hydraulic system - - - - - 1 quarts

C. Dimensions

Weight –	Sweeper Dry	6420 Pounds
	Sweeper With Fuel & Hydraulic Fluid	6770 Pounds
	Sweeper With Fuel, Hydraulic & Water	8015 Pounds

Wheel Base - 11' (132")

Total Length - 16' 4" (196")

Shipping Width - 8' (97.25")

Outside Tire to Tire Width Front – 5' 6" (66")
Outside Tire to Tire Width Rear – 5' 4" (64")

Shipping Height - 9' 8" Top of Strobe Light
9' 11" Top of Turbo
9' 10" top of Radio Antenna

Turning Radius - Inside, 16' 8"
Outside, 22"

Notes

Section 4

Prestarting Checks

BEFORE STARTING CHECKS

Before starting the engine for the first time each day:

- Visually inspect the entire machine for any damage or required repairs prior to starting the engine.
-
- Check engine oil level. Do not operate engine when oil level is below mark on dipstick.
-
- Check coolant level.
-
- On level ground check hydraulic oil level. Add oil if you need to. Do not overfill.
-
- Check engine air intake system and element.
-
- Check the cap screws located on the bell and motor housing. Tighten to 21-foot pounds torque. Check every 40 hours of use.
-
- With key on, fuel gauge will appear on display will show the amount of fuel in tank.
-
- Fuel tank capacity is 32 U S Gallons.
-
- If dirty fuel has been used, follow the procedure in your engine manual to replace filters and clean the system.
-
- If engine has not been operated for a long time, see engine manual for starting procedure.
-
- Grease the machine every 50 hours.



CAUTION: Never attempt to start sweeper by towing. Severe damage to hydrostatic transmission pump and motor will result.

Notes

Section 5

Operating the Sweeper

This section provides information on operational checks, and procedures necessary for the safe operation and maintenance of the GEEFS Mighty Sweep broom. All safety precautions and warnings must be adhered to in order to prevent injury to operation and maintenance personnel as well as innocent bystanders, equipment and property around operation area.



CAUTION: When the law requires, make sure that the flashing warning lights are turned on when traveling on, streets, roads or highways

A. Starting the Engine



WARNING: Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.

Be certain that controls are in the neutral position, park brake is set, and all persons are clear of sweeper before starting engine.

Sound horn before starting engine to clear people away from sweeper.



CAUTION: If you have any problems starting the engine, see the engine manual for the proper way to start your engine.

If you are starting the engine for the first time, refer to the engine manual for information regarding the initial break-in procedure.

Avoid overheating the engine. The temperature of the coolant, a mixture of 50% ethylene-glycol and 50% water, must not exceed 225°F.

Avoid low coolant temperature operation. Continual operation at low coolant temperature below 140°F can be harmful to the engine.

STEPS TO STARTING ENGINE

1. Place forward/reverse joystick in neutral position.
2. Raise the throttle by pressing the rocker throttle on the joystick.
3. Sound horn before starting engine.
4. Turn ignition key clockwise to the start position (Crank engine).



CAUTION: Do not operate starter motor continuously for more than 30 seconds. Allow starter motor to cool for at least 2 minutes between unsuccessful attempts.

NOTE: If the forward/neutral/reverse joystick is not in the neutral position the machine **will not start**.

5. Lower the engine RPM to the idle position as soon as the engine starts.
7. After engine has started, check all gauges for proper levels of operation.



CAUTION: Avoid full throttle operation when engine is cold.

When the sweeper has set for a long period of time, start the engine and let it idle at the low RPM for 5 minutes minimum. This will allow the hydraulic pump to charge the system.

B. Starting the Engine In Cold Weather



CAUTION: Be cautious when starting the engine in cold weather (below 32°F).

If the temperature is below 10°F, preheat the hydraulic oil to 32°F before starting the engine. This will prevent damage to the hydraulic pumps and motors.

Let the engine idle at the low RPM for 5 minutes minimum. This will allow the hydraulic oil to warm and the hydraulic pump to charge the system.

Check your engine manual before using starter fluid.

If you have any problems starting the engine, see the engine manual for the proper way to prime and start the engine.

NOTE: If the sweeper is to be operated in very cold weather on a regular basis, installation of an engine water heater is recommended. This will decrease stress and reduce wear on the engine and electrical system.

C. Stopping the Engine

IMPORTANT: Before stopping an engine that has been operating at working load, idle engine at least 2 minutes (1400 rpm maximum) with no load to cool hot engine parts.

1. Move the forward/neutral/reverse joystick to the **NEUTRAL** position.
2. Apply the park brake.
3. Lower the engine rpm by the rocker switch on top of the forward/neutral reverse joystick to **IDLE** position.
4. Turn the operator presence switch to off.
5. Turn the key to the **OFF** position.



CAUTION: Remove key from switch to prevent accidents and battery discharge.

D. Controls

Brakes-	Foot brake pedal (service brake, right foot pedal, optional location on the left) Depress to slow or halt machine movement.
	Parking Brake Lever (left side of seat on the floor) Lift and pull back handle to apply. Push forward and down to release
	Parking Brake Adjustment Knob Turn knob clockwise to increase brake tension. Turn knob counter-clockwise to decrease tension.



CAUTION: Parking brake is as its name suggests, is for holding machine when it is not in operation. Parking brake must be released when operating machine. Hydrostatic transmission provides enough power to easily overcome parking brake when it is engaged.

Engine Throttle - Rocker Switch on top of the forward/neutral/reverse joystick press right or left to raise or lower engine rpm.

Joystick Controls - Move the control to the right to swing the broom to the right.
Move the control to the left to swing the broom to the left.
Move the control back will lift the broom.
Move the control forward will lower the broom.
Switch on handle will turn the broom rotation “ON” or “OFF” (each time the switch is toggled it will cycle the broom motor, “ON”/”OFF”/”ON”)

Broom Float Switch - Turns the broom float “ON” or ”OFF”. Hydraulic counterbalance circuit functions only when switch is in turned “ON”. NOTE: Swing arm will not operate when float is ON.

Hydraulic Counterbalance Control - With broom float switch “ON”, turn adjuster clockwise to decrease sweeping pattern, turning adjuster counterclockwise to increase down pressure and increase sweeping pattern.

Steering Wheel - Wheel controls hydraulic power steering through fluid link to cylinders.



CAUTION: System does not return front wheels to a straight-ahead position when the operator releases the wheel. When the wheel is released, the wheel will remain in that position.

Operator’s Seat Adjustment - Moving the lever on the left side of seat base allows for adjustment forward and back. The knob located behind the seat will adjust the height of the seat.

Heater (if Equipped) - Three (3) speed fan switch located on the left hand side of cab on AC/heater control panel.

Wipers, Front and Rear (if Equipped) - A switch is located on the left side of the steering column.

Strobe Light Switch - Located on the front control console

Back-up Alarm - Automatically sounds alarm whenever the Forward/neutral/Reverse is in the reverse position.

Traffic Horn - Electric horn operated by horn button switch on center of steering wheel.

NOTE: Engine must be “ON” or switch in accessory position.

Headlights - A push/pull switch located on the right hand side of the steering column operates the working lights.

Turn Signals and Flashers - Controlled by lever attached to steering column. Move lever up to signal right turn, move lever down to signal left turn. Pull hazard lever out to activate emergency flashers.

NOTE: Operation of turn signal will deactivate hazard-warning flashers. Operator must turn signal off manually.

Dome Light - Switch is located on the overhead pressurize fan unit.



WARNING: DO NOT USE ETHER (starting fluids) unless specifically instructed to do so by the engine manufacturer.

Water Spray System (If equipped) - One-quarter turn valve must be open to allow fluid transfer through the strainer to the pump. Turn the pump “ON” with a toggle switch located on left side of steering column. The pressure can be adjusted by turning the knob clockwise on the regulator valve until desired pattern and flow is achieved.

IMPORTANT: Standard system includes TEE-Jet 8001 nozzle tips. If additional volume is desired, tip size can be changed.

E. Instrumentation (Gauges and Warning Lights located on the display located on the console with the steering column)

Tachometer - Indicates the engine operating speed in 100-RPM increments.

IMPORTANT: Engine RPM also controls broom RPM.

Hour Meter – Included with tachometer. Indicates hours in tenths that the engine has operated.

Engine Oil Pressure Gauge - Indicates the engine oil pressure.

IMPORTANT: Engine oil pressure will drop slightly as engine temperature increases.

Engine Water (coolant) Temperature Gauge - Indicates the coolant temperature. Normal operating temperature should be between 165° to 217° F (73° to 103° C).



CAUTION: Do not operate engine over 225° F or engine damage could result.

Explosive release of fluids from pressurized cooling system can cause serious burns.

Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to the first stop then relieve the pressure before removing completely.

Volt Meter - Indicates the state of the battery charge, in volts.

Amp Meter - Indicates battery amperage draw.

Fuel Level Gauge - Indicates the level of the fuel in the fuel tank.

Hydraulic Fluid Temperature - Indicates the hydraulic oil temperature is in the reservoir.

Warning Indicator Lights - Park brake indicator: Indicates parking brake is set when lit.

Engine Warnings - Low oil pressure with audible indicator: Indicates oil pressure is below recommended limits when lit and buzzer is audible.

High Water temperature indicator: Indicates coolant temperature is above engine manufacturer's recommendation limits.

Engine Faults: All engine faults are located on the display.

Hydraulic Fluid Level Indicator - Located in the engine compartment on the hydraulic reservoir. Sight gauge shows the hydraulic oil level in the reservoir. Level should be kept midway between lines.

IMPORTANT: Check the 5/16 cap screws located on the bell and motor housing every 40 hours for tightness. Tighten to 21-foot pounds torque.

G. Towing the Sweeper

If the sweeper cannot be moved under its own power, a trailer should transport it. If this is not possible and machine must be moved follow the instructions below.

IMPORTANT: All brakes are functional without engine operation.



WARNING: Steering will function without engine power but will be considerable slower than normal.

Towing is for emergency movement only.

Do not exceed 34 MPH.

1. Remove the drive shaft from the rear axle differential and slide the front yoke off the drive motor shaft.
2. Attach the towrope, chain or strap to the tie down rings that are provided with the machine.

Description of Operation

Setup:

The Setup screen on the DP250 display has setting for screen brightness, low fuel level, foot pedal selection and input calibration.

This screen is password protected. Please contact factory for correct password.

Press the SELECT button to select the digit. Press the Up or Down arrow button to adjust the value. Press the ENTER button to submit the password.

If the password is correct the Setup screen will appear. If the wrong password is entered the display will return to the Main screen.

Note: Pressing the Enter button without changing the digits will return the display to the Main screen.

Screen brightness:

The brightness can be set to manual or automatic adjustment. In automatic the DP250 uses the built in light sensor to determine screen brightness.

Low Fuel Level Warning:

This is the percentage of fuel left in the tank where the low fuel indicator will come on the main screen of the DP250 display.

Foot Pedal Installed:

This will be set to YES if the machine is equipped with the optional electronic foot pedal for machine speed control. If installed there is also a switch to select between Joystick and foot pedal control.

Reset Joy/Ped/Pot Cal:

This is used to clear any stored calibration values. Typically it would only be used if one of the input devices was repaired or replaced.

Calibration:

The joystick, foot pedal and the broom down pressure pot must be calibrated for the controller to be operational. The faults screen on the DP250 will show the NO CAL fault if the device has not been calibrated.

Calibration :

1. Place the joystick in the center position, the pressure pot in the full clockwise position and the foot pedal in its normal up position.
2. Press the SELECT button to select JOY/PED/POT CAL.
3. Press the down arrow button to clear any stored values.
4. Wait approx. 5 seconds for the controller to capture the joystick CEN position, and the MAX position of the pot and foot pedal.
5. Shift the joystick to the full forward position, the pressure pot to the full counter clockwise position and press the foot pedal to the full down position.

6. Wait approx. 5 seconds for the controller to capture the joystick MAX position, and the MIN position of the pot and foot pedal.
7. Shift the joystick to the full reverse position (release the foot pedal).
8. Wait approx. 5 seconds for the controller to capture the joystick MIN position.
9. Return the joystick to neutral.

Propel Function:

The hydro drive propels the vehicle and a hydraulic driven broom sweeps the road surface.

The hydro drive can be controlled two ways; with the foot pedal and joystick or with the joystick alone. Selection of the control is made with the Joystick / Foot Pedal selector switch. With the switch in the Joystick position the machines direction and speed are controlled with the joystick alone. With the switch in the Foot Pedal position the machine direction is controlled with the joystick and the speed is controlled with the foot pedal.

There are two propel modes: Work Mode and Travel Mode. In work mode the top speed of the machine is limited to 10 mph. The joystick or foot pedal (optional) will operate full stroke over this limited value giving the operator very precise speed control.

In Travel mode the machine is allowed to achieve full speed.

Enable the hydro drive: Place the Run/Stop Switch in the Run position, the joystick in neutral and release the park brake to enable the propel function.

Once enabled, the propel function will be disabled in the event of a propel system fault, if the Run/Stop Switch is placed in the Stop position or the park brake is applied..

Neutral Timeout: There is also a neutral timeout that will disable propel regardless of the position of the Run/Stop switch. If the joystick is in neutral for a given amount of time (set by the service tool) the propel function is disabled and the DP250 display will show a warning that the Neutral Timeout has occurred.

The operator must either press the brake pedal or place the Run Stop switch to the stop position and then back to Run to regain control. The neutral timeout will not occur as long as the brake pedal is pressed or the park brake is set.

Engine Control Function:

The engine RPM is controlled from a rocker switch on the joystick handle. The RPM command is adjusted by increments of 10 with each press of the button. If the button is held down the command will scroll up (or down) until it reaches the max (or minimum) settings, which are service tool adjustable.

The system also has an anti-stall function that will back off the propel command in the event that the engine RPM droops below the commanded value.

Broom Control:

The operator can control Broom On/Off, Left/Right and Lift/Lower functions all with the dual axis joystick. The Run/ Stop switch must be in the Run position. The push button on the handle will turn the broom on and off. Pull the joystick back to lift the broom, push the joystick forward to lower it. Move the joystick left and the broom will turn left and likewise for broom right.

Broom Float: In addition to the joystick functions the operator can control the broom down pressure with the down pressure potentiometer. To activate place the Float switch in the Float position.

The down pressure coil will not energize if the engine is not running or the Run / Stop switch is in the Stop position.

DP250 Screens

Startup Screen



Main Screen



Faults Screen



Engine Faults Screen



Hydraulics Screen



Setup Screen



Notes

Section 6

Shipping

NOTE: GEFFS Manufacturing, Inc. Mighty Sweep broom is shipped fully assembled from the factory and is ready to be placed into operation.

A. Shipment

Shipping from one location to another should be done according to the following list of recommended procedures and practices for safe shipment.

1. Mighty Sweep should be transported on a trailer capable of hauling 6000 GVW and of suitable size to accommodate over all machine dimensions.
2. Machine should be backed onto the trailer under its own power. If machine must be winched onto trailer, follow the towing instructions.
3. Use the tie down rings that are provided on the bottom of the frame (front and rear).



WARNING: When the machine is positioned on the trailer and tied down, parking brake should be applied before transporting.

IMPORTANT: The machine must be transported backwards on the trailer.

The broom should be positioned 90° to the frame that is the narrowest width position for shipment.

The machine should be shipped with the broom in the raised position to prevent folding of the bristles against the trailer deck.

4. All electrical accessories and switches should be shut off.
5. All cab doors and engine compartment doors should be latched and locked before shipping.

IMPORTANT: Latch the doors closed during transportation.

6. Fluid tank on the front of machine should be drained before transporting machine. All the valves should be shut. (If equipped)

B. Unloading



CAUTION: Exercise extreme caution during the unloading of the machine. Method of transportation and type of equipment used for transporting will dictate the procedure necessary.

Personal operating the equipment during unloading should be familiar with its operation and be thoroughly aware of all appropriate information contained in this manual regarding safety and operating the machine.

Due to the design and function of the machine it is preferable to drive the sweeper under its own power from the trailer. A suitable unloading area and facilities will be necessary depending on the type of trailer used for transporting.

Review the shipment procedures and follow in reverse to safely unload the machine. All safety precautions apply to the unloading process.

C. Receipt Inspection

Inspect newly arrived sweepers immediately for shipping damage. Note any damages or shortages on the shipping documents. Follow the inspection checklist below before putting the unit into operation.

1. Check unit for obvious structural or cosmetic damage.
2. Check tires for damage and proper inflation pressure and the lug nuts for tightness.
3. Check overall machine for loose or missing fasteners.
4. Check engine coolant level.
5. Check engine oil level.
6. Check hydraulic system fluid level.
7. Check engine air intake system for loose clamps or connections.
8. After machine has run for several minutes check for leaks in the hydraulic system, engine oil system and engine coolant system.

Section 8

This section contains information concerning regularly schedules servicing and preventative maintenance. Personal servicing this machine should keep accurate and complete records of the service preformed. The schedule established herein is a minimum. For service or maintenance beyond the scope of this chapter, contact components manufacturer’s distributor or dealer. Operating personnel must perform service checks regularly. If abnormal conditions are detected, inform maintenance personnel immediately.

Lubrication Chart

Geffs Manufacturing, Inc. uses only Pennzoil products for their lubrication needs. The following list is a competitive cross-reference list for these Pennzoil products. Other brands of lubricant can be used if it meets the same standard as the brands listed below. Hydraulic oil must meet the ISO 32 standard. Hydraulic oil must be filtered with a 3-micron filter before adding the oil to the system. Always use a good quality of multi-purpose grease to lubricate bearings, u-joints, and axle pivot.

Brands	Hydraulic System	Engine Oil	Axle Oil	Brake Fluid
Pennzoil	AW 32 ISO 32	SAE 15W-40	SAE 80W90 GL5	DOT 3
Amoco	AW 32	SAE 15W-40	SAE 80W90	DOT 3
Chevron	AW Hydraulic Oil 32	SAE 15W-40	SAE 80W90	DOT 3
Conoco	Super Hydraulic Oil 32	SAE 15W-40	SAE 80W90	DOT 3
Exxon	Nuto H 32	SAE 15W-40	SAE 80W90	DOT 3
Gulf		SAE 15W-40	SAE 80W90	DOT 3
Mobil	AW Hydraulic Oil 32	SAE 15W-40	SAE 80W90	DOT 3
Quaker State		SAE 15W-40	SAE 80W90	DOT 3
Texaco	Rando HD 32	SAE 15W-40	SAE 80W90	DOT 3
Valvoline	AW Hydraulic Oil 32	SAE 15W-40	SAE 80W90	DOT 3

Lubrication Maintenance Schedule

Maintenance Schedule	<u>New Done At Factory Before Shipping</u>	<u>Daily</u>	<u>Bi-Weekly Every 25 Hours</u>	<u>Weekly or Every 50 Hours</u>	<u>Yearly or Every 250 Hours</u>	<u>See Product Manual For Time</u>	<u>If Over Heats</u>
Engine Oil Level Check		X			X		X
Engine Radiator Level Check		X			X	X	X
Axle Differential Level Check	X			X	X		X
Hydraulic Tank Oil Level Check	X			X	X		X
Engine Oil & Filter Change	X				X	X	X
Hydraulic Filters Change	X				X		X
Hydraulic Oil Change *	X						X
Bearings Grease				X	X		X
Front Axle Pivot Grease			X		X		
U-joints Grease				X	X		
Engine Air Cleaner Check		X			X		
Steering Rod Ends				X			
Steering Cylinder Pivot Mount				X			
Broom Arm Pivot				X			
2-Speed Gearbox	X				X		X

* Change Hydraulic Oil every 1000 hours with filtered oil.

Section 8

This section contains information concerning regularly schedules servicing and preventative maintenance. Personal servicing this machine should keep accurate and complete records of the service performed. The schedule established herein is a minimum. For service or maintenance beyond the scope of this chapter, contact components manufacturer's distributor or dealer. Operating personnel must perform service checks regularly. If abnormal conditions are detected, inform maintenance personnel immediately.

Lubrication Chart

Geffs Manufacturing, Inc. uses only Pennzoil products for their lubrication needs. The following list is a competitive cross-reference list for these Pennzoil products. Other brands of lubricant can be used if it meets the same standard as the brands listed below. Hydraulic oil must meet the ISO 32 standard. Hydraulic oil must be filtered with a 3-micron filter before adding the oil to the system. Always use a good quality of multi-purpose grease to lubricate bearings, u-joints, and axle pivot.

Brands	Hydraulic System	Engine Oil	Axle Oil	Brake Fluid
Pennzoil	AW 32 ISO 32	SAE 15W-40	SAE 80W90 GL5	DOT 3
Amoco	AW 32	SAE 15W-40	SAE 80W90	DOT 3
Chevron	AW Hydraulic Oil 32	SAE 15W-40	SAE 80W90	DOT 3
Conoco	Super Hydraulic Oil 32	SAE 15W-40	SAE 80W90	DOT 3
Exxon	Nuto H 32	SAE 15W-40	SAE 80W90	DOT 3
Gulf		SAE 15W-40	SAE 80W90	DOT 3
Mobil	AW Hydraulic Oil 32	SAE 15W-40	SAE 80W90	DOT 3
Quaker State		SAE 15W-40	SAE 80W90	DOT 3
Texaco	Rando HD 32	SAE 15W-40	SAE 80W90	DOT 3
Valvoline	AW Hydraulic Oil 32	SAE 15W-40	SAE 80W90	DOT 3

Lubrication Maintenance Schedule

Maintenance Schedule	<u>New Done At Factory Before Shipping</u>	<u>Daily</u>	<u>Bi-Weekly Every 25 Hours</u>	<u>Weekly or Every 50 Hours</u>	<u>Yearly or Every 250 Hours</u>	<u>See Product Manual For Time</u>	<u>If Over Heats</u>
Engine Oil Level Check		X			X		X
Engine Radiator Level Check		X			X	X	X
Axle Differential Level Check	X			X	X		X
Hydraulic Tank Oil Level Check	X			X	X		X
Engine Oil & Filter Change	X				X	X	X
Hydraulic Filters Change	X				X		X
Hydraulic Oil Change *	X						X
Bearings Grease				X	X		X
Front Axle Pivot Grease			X		X		
U-joints Grease				X	X		
Engine Air Cleaner Check		X			X		
Steering Rod Ends				X			
Steering Cylinder Pivot Mount				X			
Broom Arm Pivot				X			
2-Speed Gearbox	X				X		X

* Change Hydraulic Oil every 1000 hours with filtered oil.

Section 10

Trouble Shooting

Proper troubleshooting begins with an organized approach to the problem at hand. Begin with investigation of the most probable cause, following the guidelines below.

Study the problem thoroughly before taking action.

Did warning signs precede the problem? If so, what were they? What would they indicate?

Is scheduled maintenance current on all parts and systems involved?

Has similar trouble occurred before? What action was taken at that time?

Can engine be operated without further damage?

Check the most convenient things first.

Don't begin major work before checking all other possibilities.

Reconsider all known facts and clues before proceeding to more in-depth work.

Remember, failure of certain parts may be caused by malfunction of another part of system.

The troubleshooting charts lists problems that might be encountered in the operation of the sweeper. The solution listed may direct the repairperson to a possible faulty component.



WARNING: Maintenance and repairs should not be attempted by other than experienced mechanics or personnel under the direct supervision of an experienced mechanic. Failure to comply may result in damage to equipment and/or injury or death to personnel.



CAUTION: Review and follow all safety instructions before performing any maintenance. To prevent injury, never lubricate or service sweeper, engine or clean the machine while it is running. Engine must be off, park brake engaged, and key removed.

Extreme care should be taken to assure that no foreign matter enters your hydraulic system. Always clean off fittings and hoses before connecting them together. If lines are disassembled, cap both ends to eliminate foreign matter from entering your hydraulic system. Severe damage may occur to the sweeper hydraulic system.

Do not use Teflon tape: use thread sealant.

Hydraulic oil must be filtered with a 3-micron filter before adding the oil to the hydraulic system.

A. Engine

If there are any problems with the engine or it needs servicing, refer to the manufacture's manual for the proper maintenance and trouble shooting procedures. If you need assistance contact your local engine dealer or Geffs Manufacturing, Inc.

Engine will not crank over. (See also Section H Electrical System)

1. If the transmission Forward/Neutral/Reverse Joystick is not in the neutral position the engine **will not start**.
2. Check the battery cables and terminals.
3. Check the starter cables and terminals.
4. Check the starter solenoid.
- 5.

B. Hydrostatic Transmission (6000 psi maximum system pressure)

1. Sweeper fails to move under power.
 - a. Parking brake set.
 - b. Joystick in neutral position
 - c. neutral time out occurred step on brake pedal to engage.
 - d. Inadequate oil level in hydraulic reservoir.
 - e. Drive coupler missing or damaged.
 - f. Inadequate oil flow through transmission suction filter.
 - g. Driveline mechanical failure.

For detailed troubleshooting information on hydrostatic transmission refer to Eaton parts and repair manual available from and Eaton representative.

C. Hydraulic System (1500 psi maximum system pressure)

1. Thoroughly review description of hydraulic system in this manual.
2. Use logical steps to determine cause of malfunction.
3. Identify the function or functions that require troubleshooting.
4. If possible, trace malfunction to source: pump, control, motor or cylinder.
5. Determine if pressure or volume is inadequate for function as specified.
6. Hydraulic system pressures.
 - a. Priority circuit = 1500 psi (Steering, Swing and Lift)
 - b. Main circuit = 1500 psi (Broom speed)
7. Hydraulic system flows.
 - a. Priority circuit = 4 gpm (Steering, Swing and Lift)
 - b. Main circuit = 23 gpm (Broom speed)

All the hydraulic functions with the exception of the hydrostatic transmission system are run off of the small pump. The controls for the steering, swing and broom lift are in the integral control valve block. After defining the system that has failed, refer to the cartridge or cartridges that control that system.

D. Integral Control Valve

Problem	Possible cause	Correction
No power steering	Inadequate fluid flow to steering orbital valve.	Inspect or replace priority valve cartridge
	Inadequate pressure to steering orbital valve.	Inspect, clean or replace relief valve cartridge
No broom swing or lift	Inadequate flow from pump	Inspect or replace priority valve cartridge
	Inadequate pressure	Inspect, clean or replace relief valve cartridge
Inappropriate swing or lift speed	Fluid flow to cylinders too high or low	Priority valve cartridge or priority flow control orifice in pump cover.

E. Steering

Most steering problems can be corrected if the problem is properly defined. The entire steering system should be evaluated before removing any components. The steering control unit is generally not the cause of most steering problems. The following is a list of steering problems along with possible causes and suggested corrections.

Problem	Possible cause	Correction
Slow steering, hard steering, or loss of power assist.	Worn or malfunctioning pump.	Replace pump.
	Stuck flow divider piston.	Replace flow divider.
	Worn pump compensator allowing the system pressure to be less than specified.	Replace pump and compensator.
	Malfunctioning relief valve allowing the system pressure to be less than specified.	Replace the relief valve.
	Overloaded steer axle.	Reduce load.
Wandering - vehicle will not stay in a straight line.	Air in the system due to: Low level of hydraulic fluid, pump cavitation, leaky fitting or pinched hose.	Correct by adding fluid Repair or replace hose.
	Worn mechanical linkage or bending of	Repair or replace linkage

	<p>linkage.</p> <p>Bent cylinder rod.</p> <p>Loose cylinder piston.</p> <p>Severe wear in steering control unit.</p>	<p>Repair or replace cylinder</p> <p>Repair or replace cylinder.</p> <p>Replace the steering control unit.</p>
Drift - vehicle veers slowly in one direction.	Worn or damaged steering linkage.	Replace linkage and align front end.
Slip - a slow movement of steering wheel fails to cause any movement of steered wheels.	<p>Leakage of cylinder piston seals.</p> <p>Worn steering orbital.</p>	<p>Replace seals.</p> <p>Replace steering orbital.</p>
Temporary hard steering or hang-up.	Thermal shock. *	Check unit for proper operation and cause of thermal shock. *
Erratic steering	<p>Air in system due to low hydraulic fluid level, pump cavitation or leaky fitting.</p> <p>Pinched hose.</p> <p>Loose cylinder piston.</p> <p>Thermal Shock* damage.</p> <p>Sticking flow control spool.</p>	<p>Correct fluid level.</p> <p>Repair or replace hose.</p> <p>Replace cylinder</p> <p>Replace steering orbital.</p> <p>Replace flow control valve.</p>
Spongy or soft steering.	<p>Air in hydraulic system. Most likely air trapped in cylinders or lines.</p> <p>Low fluid level.</p>	<p>Bleed air out of system. Placing ports on top of the cylinder will help prevent air trapping.</p> <p>Add fluid and check for leaks.</p>
Free wheeling - steering turns with slight resistance but results in little or no steered wheel action.	<p>Leaking crossover relief or anti-cavitation valve in cylinder lines.</p> <p>Piston seal blown out.</p>	<p>Repair or replace the valve.</p> <p>Correct and replace seal.</p>
Free wheeling - steering wheel turns freely with no feeling of pressure and no action on steered wheels.	<p>Steering column upper shaft is loose or damaged.</p> <p>Lower spindle of column may be damaged or broken.</p> <p>Steering orbital has a lack of fluid. This can happen on start-u, after repair, or long</p>	<p>Tighten steering wheel nut or replace damaged part.</p> <p>Repair or replace column.</p> <p>Usually starting engine and allowing system to pressurize will cure problem.</p>

	<p>periods of non-use.</p> <p>No flow to steering orbital can be caused by:</p> <ol style="list-style-type: none"> 1. Low fluid level. 2. Ruptured hose. 3. Internal steering orbital damaged due to thermal shock.* 	<p>Add fluid and check for leaks.</p> <p>Replace hose.</p> <p>Replace steering orbital.</p>
Excessive free play at steered wheels.	<p>Broken or worn linkage between cylinder and steered wheels.</p> <p>Leaky cylinder seals.</p>	<p>Check for loose fitting bearings and anchor points in steering linkage between cylinder and steered wheels.</p> <p>Replace cylinder seals.</p>
Steering unit locks up.	<p>Large particles in meter section.</p> <p>Insufficient hydraulic power.</p> <p>Severe wear and/or broken pin.</p> <p>Thermal Shock*</p>	<p>Clean unit.</p> <p>Check hydraulic power supply.</p> <p>Replace the unit.</p> <p>Replace the steering orbital.</p>
Steering wheel oscillates or turns by itself.	<p>Parts assembled wrong.</p> <p>Steering orbital improperly timed.</p> <p>Lines connected to wrong ports.</p>	<p>Correctly install.</p> <p>Correct timing.</p> <p>Reconnect lines correctly.</p>
Steered wheels turn wrong direction when operator activates steering wheel.	<p>Lines connected to wrong cylinder ports.</p>	<p>Reconnect lines correctly.</p>
Steering wheel kicks at start of steering.	<p>No inlet check valve on steering orbital.</p>	<p>Install a check valve.</p>

*Thermal Shock – a condition caused when the hydraulic system is operated for sometime without turning the steering wheel so that fluid in the reservoir and system is hot and the steering orbital is relatively cool (more than 50°F temperature differential). When the steering wheel is turned quickly the result is temporary seizure and possible damage to internal parts of the steering orbital. Total freewheeling may follow the temporary seizure.

F. Broom Swing and Lift

The entire system should be evaluated before removing any components. The following is a list of problems with possible causes and suggested corrections.

Problem	Possible Cause	Correction
Slow swing or lift, loss of power.	Worn or malfunctioning pump. Stuck flow divider cartridge. Stuck relief valve cartridge. Worn pump allowing system pressure to be less than specified.	Repair or replace pump. Repair or replace cartridge. Repair or replace cartridge. Repair or replace pump.
Surging of broom left to right.	Air in the system due to: low level of hydraulic fluid, pump cavitation, leaky fitting or pinched hose. Worn or bent mechanical linkage. Bent cylinder rod. Loose cylinder piston.	Correct by adding fluid Repair or replace hose. Repair or replace linkage. Replace cylinder. Repair or replace cylinder.
Erratic swing.	Air in the system due to: low level of hydraulic fluid, pump cavitation, leaky fitting or pinched hose. Loose cylinder piston. Sticking flow divider valve.	Correct by adding fluid Repair or replace hose. Replace cylinder. Repair or replace.
Excessive free play.	Broken or worn linkage between cylinder and broom. Leaky cylinder.	Repair or replace. Repair or replace.
Broom will not lower to float position.	Counterbalance control adjustment overriding control valve.	Readjust control.

G. Broom Drive

The entire system should be evaluated before removing any components. The following is a list of problems with possible causes and suggested corrections.

Problem	Possible Cause	Correction
No power or inadequate power.	Worn or malfunctioning pump or motor.	Repair or replace pump or motor.
	Stuck relief valve cartridge.	Repair or replace.
	Low system pressure by worn pump.	Repair or replace pump.
Surging of broom rpm.	Air in the system due to: low level of hydraulic fluid, pump cavitation, leaky fitting or pinched hose.	Correct by adding fluid Repair or replace hose.

H. Electrical System

Engine Status	Voltmeter Reading	Indication	Correction
Running	13.5 - 14 volts	Normal Condition	None
Running	Less than 13.5 volts or More than 14.0 volts	Alternator or Voltage Regulator Malfunction	Contact Dealer
Will Not Start	12-12.5 volts	Weak Battery	Charge Battery
Will Not Start	Less than 12 volts	Weak Battery or Defective Battery Cell	Charge Battery or Replace Battery
Stopped	Excessive Current Draw	Short Circuit	Inspect System



Geffs Manufacturing, Inc.
P.O. Box 4885
Pocatello, Idaho 83205-4885
208-232-1100



USER GUIDE

GEFFS MANUFACTURING INC.

**MIGHTY SWEEP
VEHICLE CONTROL MANUAL**

Table of Contents

I.	Revisions.....	2
II.	Software Specification.....	3
III.	Description of Operation.....	3
IV.	I/O Table PLUS 1, MC050-20.....	5
V.	I/O Table PLUS 1, DP250.....	6
VI.	DP250 Screens	7
VII.	Service Tool Screens.....	10

I. Revisions

LEVEL	DESCRIPTION – ECO NUMBER	DATE	BY
100	Created	2/7/11	AP
101	Moved input for hydraulic oil temp.	2/10/11	AP
102	Added park brake indicator. Added Float On input.	2/17/11	AP
103	Added password protect to Setup screen	2/17/11	AP

II. Software Specification

Module	NODE #	HWD Version	Baud Rate	Program Number
MC050-020	11	1010xxxxv210	250	SA43xxxxx
DP250	12	7003xxxxv100	250	SA43xxxxx

III. Description of Operation

Setup:

The Setup screen on the DP250 display has setting for screen brightness, low fuel level, foot pedal selection and input calibration.

This screen is password protected. The default password is **208**, but can be changed with the laptop service tool.

Press the SELECT button to select the digit. Press the Up or Down arrow button to adjust the value. Press the ENTER button to submit the password.

If the password is correct the Setup screen will appear. If the wrong password is entered the display will return to the Main screen.

Note: Pressing the Enter button without changing the digits will return the display to the Main screen.

Screen brightness:

The brightness can be set to manual or automatic adjustment. In automatic the DP250 uses the built in light sensor to determine screen brightness.

Low Fuel Level Warning:

This is the percentage of fuel left in the tank where the low fuel indicator will come on the main screen of the DP250 display.

Foot Pedal Installed:

This will be set to YES if the machine is equipped with the optional electronic foot pedal for machine speed control. If installed there is also a switch to select between Joystick and foot pedal control.

Reset Joy/Ped/Pot Cal:

This is used to clear any stored calibration values. Typically it would only be used if one of the input devices was repaired or replaced.

Calibration:

The joystick, foot pedal and the broom down pressure pot must be calibrated for the controller to be operational. The faults screen on the DP250 will show the NO CAL fault if the device has not been calibrated.

Calibration :

1. Place the joystick in the center position, the pressure pot in the full clockwise position and the foot pedal in its normal up position.
2. Press the SELECT button to select JOY/PED/POT CAL.
3. Press the down arrow button to clear any stored values.
4. Wait approx. 5 seconds for the controller to capture the joystick CEN position, and the MAX position of the pot and foot pedal.
5. Shift the joystick to the full forward position, the pressure pot to the full counter clockwise position and press the foot pedal to the full down position.
6. Wait approx. 5 seconds for the controller to capture the joystick MAX position, and the MIN position of the pot and foot pedal.
7. Shift the joystick to the full reverse position (release the foot pedal).
8. Wait approx. 5 seconds for the controller to capture the joystick MIN position.
9. Return the joystick to neutral.

Propel Function:

The hydro drive propels the vehicle and a hydraulic driven broom sweeps the road surface. The hydro drive can be controlled two ways; with the foot pedal and joystick or with the joystick alone. Selection of the control is made with the Joystick / Foot Pedal selector switch. With the switch in the Joystick position the machines direction and speed are controlled with the joystick alone. With the switch in the Foot Pedal position the machine direction is controlled with the joystick and the speed is controlled with the foot pedal.

There are two propel modes: Work Mode and Travel Mode. In work mode the top speed of the machine is limited to a service tool adjustable value. The joystick or foot pedal will operate full stroke over this limited value giving the operator very precise speed control. In Travel mode the machine is allowed to achieve full speed.

Enable the hydro drive: Place the Run/Stop Switch in the Run position, the joystick in neutral and release the park brake to enable the propel function. Once enabled, the propel function will be disabled in the event of a propel system fault, if the Run/Stop Switch is placed in the Stop position or the park brake is applied..

Neutral Timeout: There is also a neutral timeout that will disable propel regardless of the position of the Run/Stop switch. If the joystick is in neutral for a given amount of time (set by the service tool) the propel function is disabled and the DP250 display will show a warning that the Neutral Timeout has occurred.

The operator must either press the brake pedal or place the Run Stop switch to the stop position and then back to Run to regain control. The neutral timeout will not occur as long as the brake pedal is pressed or the park brake is set.

Engine Control Function:

The engine RPM is controlled from a rocker switch on the joystick handle. The RPM command is adjusted by increments of 10 with each press of the button. If the button is held down the command will scroll up (or down) until it reaches the max (or minimum) settings, which are service tool adjustable.

The system also has an antistall function that will back off the propel command in the event that the engine RPM droops below the commanded value.

Broom Control:

The operator can control Broom On/Off, Left/Right and Lift/Lower functions all with the dual axis joystick. The Run/ Stop switch must be in the Run position. The push button on the handle will turn the broom on and off. Pull the joystick back to lift the broom, push the joystick forward to lower it. Move the joystick left and the broom will turn left and likewise for broom right.

Broom Float: In addition to the joystick functions the operator can control the broom down pressure with the down pressure potentiometer. To activate place the Float switch in the Float position.


The down pressure coil will not energize if the engine is not running or the Run / Stop switch is in the Stop position.

IV. I/O Table MC050-20:



MC050-020-00000 PLUS 1™ Controller


Dimensions and Pin Assignment



MC050-020-00000 mounting dimensions.

Power ground -	C1-P1
Power supply +	C1-P2
CAN1 +	C1-P3
CAN1 -	C1-P4
AIN/CAN1 shield	C1-P5
DIN	C1-P6
DIN	C1-P7
5 V DC sensor power +	C1-P8
Sensor power ground -	C1-P9
DIN	C1-P10
DIN	C1-P11
DIN	C1-P12
DIN	C1-P13
DIN	C1-P14
DIN	C1-P15
DIN	C1-P16
DIN	C1-P17
DIN/AIN	C1-P18
DIN/AIN	C1-P19
CAN2 +	C1-P20
CAN2 -	C1-P21
AIN/CAN2 shield	C1-P22
DIN/AIN	C1-P23
DIN/AIN	C1-P24
DIN/AIN/FreqIN	C1-P25

DIN/AIN/FreqIN	C1-P26
DIN/AIN/FreqIN	C1-P27
DIN/AIN/FreqIN	C1-P28
DIN/AIN/FreqIN	C1-P29
DIN/AIN/FreqIN	C1-P30
AIN/Temp/Rheo	C1-P31
AIN/Temp/Rheo	C1-P32
DOUT	C1-P33
DOUT	C1-P34
DOUT	C1-P35
DOUT	C1-P36
DOUT	C1-P37
DOUT	C1-P38
DOUT/PVE Pwr1	C1-P39
DOUT/PVE Pwr2	C1-P40
PWMOUT/DOUT/PVE 1OUT	C1-P41
PWMOUT/DOUT/PVE 1OUT	C1-P42
PWMOUT/DOUT/PVE 1OUT	C1-P43
PWMOUT/DOUT/PVE 2OUT	C1-P44
PWMOUT/DOUT/PVE 2OUT	C1-P45
PWMOUT/DOUT/PVE 2OUT	C1-P46
Power supply +	C1-P47
Power supply +	C1-P48
Power supply +	C1-P49
Power supply +	C1-P50



MC050-020-00000 50 pin connector.

Above pinouts are for device pins.
Use care when wiring mating connector.

Specifications

Product Parameters	
Supply voltage:	9 to 36 V
Operating temperature (ambient):	-40 to 70° C
Storage temperature:	-40 to 85° C
IP rating:	IP 67
EMI/RFI rating:	100 V/M
Weight:	0.53 kg (1.16 lb)
Vibration:	IEC 60068-2-64
Shock:	IEC 60068-2-27 test Ea
Maximum current:	40 A

Ordering Information	Part Number
MC050-020-00000	10100994
Related Products	Part Number
USB to CAN communicator	1091099
Deutsch mating connector bag assembly	10100946
PLUS 1 GUIDE single user license	10101000
Comprehensive Technical Information	
PLUS 1 Controller Family Technical Information manual order number:	DKMH.PB.700.A1.02/520L0719
Product literature is on line at:	www.sauer-danfoss.com

© Copyright 2004, Sauer-Danfoss. All rights reserved. Contents subject to change.
Sauer-Danfoss, Sauer-Danfoss logotype and PLUS 1 are trademarks of the Sauer-Danfoss Group.
Microsoft and Windows are trademarks of Microsoft Corporation.

DKMH.PD.760.H1.02/520L0715 01/2004

V. I/O Table DP250:



DP250 Dimensions



DP250 Series PLUS+1 Display

Mounting Panel Cutout Dimensions



DP2XX Series Model Code	
A Model Name	
DP250	Color Graphical Display
B Inputs/CAN Options	
00	1 CAN port
01	1 CAN port, 4 DIN/AIN
02	1 RedCAN port
05	User Configurable: 2 CAN ports or 1 CAN port, 4 DIN/AIN
06	User Configurable: 1 RedCAN port, 1 CAN port or 1 RedCAN port, 2 DIN/AIN
Real Time Clock/ Low Temperature Functionality	
C	
01	RTC, and LTF
D Flash Memory/Application Key	
04	16MB without Application Key
05	16MB with Application Key
E Application Log	
00	None
05	16 MB
F USB Port Type	
00	None
01	USB Device in Front
02	USB Device in Rear

DP250 Series Specifications

Processor	ARM 7 core, 16/32 bit/ 7.2 MHz
RAM	64KB on-chip, 1MB on board
FRAM	16 KB
Supply Voltage/ Current Consumption	9-63 Vdc/6.5W Heater 10W
Connector	Deutsch DTN-12
LCD Glass	TFT with 12-bit resolution
Resolution	320 x 240 pixels
Visible Area	70.08 mm x 52.56 mm [3.15 x 2.16]
IP Rating	IP67 or IP54
Operation Temperature	-30 °C — +70°C [-22°F — +158°F]
Storage Temperature	-40 °C — +85°C [-40°F — +176°F]
Weight	250g [0.5lb]
Vibration/Shock	5g/ 50g
EMC/ESD	100V/m / 15kV


The DP250 front mini-USB model option carries an IP54 ingress rating. The USB cover/plug must be in place for full IP54 protection. This model variant is recommended for in-cab installation only.

For full IP67 ingress rating of rear USB models, the cable or plug must be in place.



DP250 Binder Series 702 USB connector pin out information

1	Vbus
2	Data -
3	Data +
4	N/C
5	Ground
6	N/C
7	N/C
8	N/C



DP250 Series Deutsch 12-pin connector pin out information


1	Power ground-
2	Power supply+
3	CAN0+
4	CAN0-
5	AIN/ CAN Shield
6	See Code B option/TI
7	See Code B option/TI
8	See Code B option/TI
9	See Code B option/TI
10	DIN/AIN.FREQ IN/ CURRENT IN.RHEOSTAT
11	DIN/AIN.FREQ IN/ CURRENT IN.RHEOSTAT
12	DOUT (0.5A)

DP250 Series Ordering Information

Model	Part Num.
DP250-00-00-04-00-00	11080686
DP250-00-01-05-00-00 (EK Installed)	11075899
DP250-01-01-04-05-00	11075900
DP250-01-01-05-05-00	11077442
DP250-05-01-04-05-00	11060814
DP250-05-01-05-05-00	11077443
DP250-06-01-04-05-01	11060816
DP250-06-01-05-05-01	11077444
DP250-02-01-04-05-02	11060919

DP250 Series Accessory Information

Model	Part Num.
DP2XX Panel Mounting Kit	11079236
Deutsch 12-pin Connector Kit (DTM06-12SA)	10100944
Binder Connector and Cable Kit (Series 702)	10103497



DP250 USB mini-B connector pin out information

1	Vbus
2	Data -
3	Data +
4	Device ID (NC)
5	Ground

Use care when wiring mating connector. Diagrams show device pins.

Comprehensive technical information: DP2XX Graphical Display Family Technical Information, L102602

Sauer-Danfoss product literature is online at www.sauer-danfoss.com



VI. DP250 Screens

Startup Screen



Main Screen



Faults Screen



Engine Faults Screen



Hydraulics Screen



Setup Screen



VII. Service Tool

Main Screen

PLUS-I GUIDE Service Tool 5.0 (Not released for production) - [C:\CUSTOMERS\Gelfs Mfg\SA-4391 MIGHTY SWEEP\Programs\SERVICE TOOL\SA439151101.PID]

Diagnostic Navigator

Name	Value	Status
011 - CP_TravelModeSW	800	OFF
011 - CP_TravelMode	800	OFF
011 - CP_WorkMode	800	ON
011 - CP_EngHpmIno	U16	OFF
011 - CP_EngHpmCmd	U16	800
011 - CP_EngRPM	U16	800
011 - CP_AntiStallCmd	U16	100
011 - CP_EngHpmDec	U16	OFF
011 - CP_TSC1_ID	U32	201326595
011 - AC_Clamed	U8	ON
011 - AC_Address	U8	3
011 - AC_Failed	U8	OFF
011 - C1p02 Volt	U16	13629
011 - CP_JoyWentSW	800	ON
011 - CP_BrakePedalSW	800	OFF
011 - CP_OperatorPresentSW	800	OFF
011 - CP_PropelEnable	800	OFF
011 - CP_JoystickSelectSW	800	ON
011 - CP_JoystickMode	800	ON
011 - CP_FwdSW	800	OFF
011 - CP_FwdZero	800	ON
011 - CP_PropelJoy_mV	U16	2444
011 - CP_PropelJoySig	U16	0
011 - CP_JoyFwdCmd	U16	0
011 - CP_PumpFwdCmd	U16	0
011 - CP_FootPedal_mV	U16	552
011 - CP_FootPedalSig	U16	0
011 - CP_JoyRevCmd	U16	0
011 - CP_PumpRevCmd	U16	0
011 - CP_RevSW	800	OFF
011 - CP_RevZero	800	ON

Logging data... [Log] Requested: 1, Actual: 297 Sauer-Danfoss CG150 #0 (Channel 0) 250k

Joy/Ped/Pot Screen

PLUS-I GUIDE Service Tool 5.0 (Not released for production) - [C:\CUSTOMERS\Gelfs Mfg\SA-4391 MIGHTY SWEEP\Programs\SERVICE TOOL\SA439151101.PID]

Diagnostic Navigator

Name	Value	Status
011 - FLT_SensorPwr	800	OFF
011 - CP_PropelJoy_mV	U16	2443
011 - CP_PropelJoySig	U16	0
011 - FLT_PropelJoy	800	OFF
011 - FLT_PropelJoy_NoCal	800	OFF
011 - CP_DownPaPot_mV	U16	555
011 - CP_DownPaPotSig	U16	0
011 - FLT_DownPaPot	800	OFF
011 - FLT_DownPaPot_NC	800	OFF
011 - CP_FootPedal_mV	U16	552
011 - CP_FootPedalSig	U16	0
011 - FLT_FootPedal	800	OFF
011 - FLT_FootPedal_NC	800	OFF

Logging data... [Log] Requested: 1, Actual: 102 Sauer-Danfoss CG150 #0 (Channel 0) 250k

Faults Screen

PLUS-I GUIDE Service Tool 5.0 (Not released for production) - [C:\CUSTOMERS\Geffs Mfg\SA-4391 MIGHTY SWEEP\Programs\SERVICE TOOL\SA439151101.PID]

File View Design Log Parameter Communication Options Tools Help

Diagnostic Navigator

Name	Value	Status
New System		
ECU List		
SA4392MC101		
SA4393DP250101		
Log Functions		
MAIN		
JOY/PED/POT		
FAULTS		
BROOM		
Parameter Functions		
DEFAULTS		
ENGINE RPM		
PROPEL		
JOYSTICK		
FOOT PEDAL		
DOWN PSI POT		
SENSORS		

Graphical Overview

011 - FLT_SensorPwr BOOL	011 - FLT_U1939_Offline BOOL	011 - FLT_PropelJoy BOOL
011 - FLT_BroomOn BOOL	011 - FLT_ChargePsi BOOL	011 - FLT_PropelJoy_NoCal BOOL
011 - FLT_BroomLeft BOOL	011 - FLT_AuxPumpPsi BOOL	011 - FLT_FootPedal BOOL
011 - FLT_BroomRight BOOL	011 - FLT_HydReturnPsi BOOL	011 - FLT_FootPedal_NC BOOL
011 - FLT_BroomLift BOOL	011 - FLT_PoepFwdPsi BOOL	011 - FLT_PumpFwdCoil BOOL
011 - FLT_BroomLower BOOL	011 - FLT_HydOffEmp BOOL	011 - FLT_PumpRevCoil BOOL
011 - FLT_DownPsiPot BOOL	011 - FLT_FuelLevel BOOL	
011 - FLT_DownPsiPot_NC BOOL		
011 - FLT_BroomOnPsi BOOL		

Logging data... | Logging | Requested: 1, Actual: 78 | Sauer-Danfoss CG150 #0 (Channel 0) | 250k

Broom Screen

PLUS-I GUIDE Service Tool 5.0 (Not released for production) - [C:\CUSTOMERS\Geffs Mfg\SA-4391 MIGHTY SWEEP\Programs\SERVICE TOOL\SA439151101.PID]

File View Design Log Parameter Communication Options Tools Help

Diagnostic Navigator


Name	Value	Status
New System		
ECU List		
SA4392MC101		
SA4393DP250101		
Log Functions		
MAIN		
JOY/PED/POT		
FAULTS		
BROOM		
Parameter Functions		
DEFAULTS		
ENGINE RPM		
PROPEL		
JOYSTICK		
FOOT PEDAL		
DOWN PSI POT		
SENSORS		

Graphical Overview

011 - CP_EngineOn BOOL	011 - CP_BroomOnSW BOOL	011 - CP_OutBroomOn BOOL
011 - CP_BroomLiftSW BOOL	011 - CP_OutBroomLift BOOL	011 - CP_BroomLowerSW BOOL
011 - CP_BroomLeftSW BOOL	011 - CP_OutBroomLeft BOOL	011 - CP_BroomRightSW BOOL
011 - CP_BroomRightSW BOOL	011 - CP_OutBroomRight BOOL	
011 - CP_DownPsiPot_mV U16	011 - CP_DownPsiPotSig U16	011 - CP_OutBroomDrPsi U16

Logging data... | Logging | Requested: 1, Actual: 68 | Sauer-Danfoss CG150 #0 (Channel 0) | 250k

Defaults Parameters Screen




Press the “Upload Parameters From ECU” button.


Enter 2011 into the SETDEFPASSWORD BOXES and press the “Download Parameters to ECU” button to reset parameters to the factory defaults.

The value in the PASSWORD box is the Setup Screen password. This must only be set to a 3 digit number. Do not change unless necessary.

Engine RPM Parameters Screen



Propel Parameters Screen



Joystick Parameters Screen

PLUS-1 GUIDE Service-Tool S.0 (Not released for production) - [C:\CUSTOMERS\Gefis Mig\SA-4391 MIGHTY SWEEP\Programs\SERVICE TOOL\SA4391S1101.P1D]

File View Display Log Parameter Communication Options Tools Help

Diagnostic Navigator

- New System
- ECU List
 - SA4392MC101
 - SA4393DP250101
- Log Functions
 - MAIN
 - JOY/PED/POT
 - FAULTS
 - BROOM
- Parameter Functions
 - DEFAULTS
 - ENGINE RPM
 - PROPEL
 - ADJUSTIX**
 - FOOT PEDAL
 - DOWN PSI POT
 - SENSORS

Graphical Overview

0.11 - X1 PumpFWD U16 0	0.11 - Y1 PumpFWD U16 0	0.11 - X1 PumpREV U16 0	0.11 - Y1 PumpREV U16 0
0.11 - X2 PumpFWD U16 2000	0.11 - Y2 PumpFWD U16 1000	0.11 - X2 PumpREV U16 2000	0.11 - Y2 PumpREV U16 1000
0.11 - X3 PumpFWD U16 3000	0.11 - Y3 PumpFWD U16 2500	0.11 - X3 PumpREV U16 3000	0.11 - Y3 PumpREV U16 2500
0.11 - X4 PumpFWD U16 5000	0.11 - Y4 PumpFWD U16 4000	0.11 - X4 PumpREV U16 5000	0.11 - Y4 PumpREV U16 4000
0.11 - X5 PumpFWD U16 8000	0.11 - Y5 PumpFWD U16 7000	0.11 - X5 PumpREV U16 8000	0.11 - Y5 PumpREV U16 7000
0.11 - X6 PumpFWD U16 10000	0.11 - Y6 PumpFWD U16 10000	0.11 - X6 PumpREV U16 10000	0.11 - Y6 PumpREV U16 10000
0.11 - PropellorMaxHi U16 4700	0.11 - PropellorMaxCal U16 4359		
0.11 - PropellorMaxLow U16 4000			
0.11 - PropellorCenHi U16 3000	0.11 - PropellorCenCal U16 2561	0.11 - PropellorCenDB U16 1000	
0.11 - PropellorCenLow U16 2000			
0.11 - PropellorMinHi U16 1000	0.11 - PropellorMinCal U16 553		
0.11 - PropellorMinLow U16 300			

Summary: Sauer-Danfoss CG150 #0 (Channel 0) 250k

Foot Pedal Parameters Screen

PLUS+1 GUIDE Service Tool 5.0 (Not released for production) - [C:\CUSTOMERS\Gelfs Mfg\SA-4391 MIGHTY SWEEP\Programs\SERVICE TOOL\SA439151101.P10]

File View Design Log Parameter Communication Options Tools Help

Diagnostic Navigator

Name	Value	Status
New System		
ECU List		
SA433MC101		
SA433DP250101		
Log Functions		
MAIN		
JOY/PED/POT		
FAULTS		
BROOM		
Parameter Functions		
DEFAULTS		
ENGINE RPM		
PROPEL		
JOYSTICK		
FOOT PEDAL		
DOWN PSI POT		
SENSORS		

Graphical Overview

0.11 - PedalMaxHi U16 4700	0.11 - PedalMaxCal U16 4362		
0.11 - PedalMaxLow U16 4000			
0.11 - PedalMinHi U16 1000	0.11 - PedalMinCal U16 550		
0.11 - PedalMinLow U16 300			
0.11 - X1PedalFWD U16 0	0.11 - Y1PedalFWD U16 0	0.11 - X1PedalREV U16 0	0.11 - Y1PedalREV U16 0
0.11 - X2PedalFWD U16 2000	0.11 - Y2PedalFWD U16 1000	0.11 - X2PedalREV U16 2000	0.11 - Y2PedalREV U16 1000
0.11 - X3PedalFWD U16 3000	0.11 - Y3PedalFWD U16 2500	0.11 - X3PedalREV U16 3000	0.11 - Y3PedalREV U16 2500
0.11 - X4PedalFWD U16 5000	0.11 - Y4PedalFWD U16 4000	0.11 - X4PedalREV U16 5000	0.11 - Y4PedalREV U16 4000
0.11 - X5PedalFWD U16 8000	0.11 - Y5PedalFWD U16 7000	0.11 - X5PedalREV U16 8000	0.11 - Y5PedalREV U16 7000
0.11 - X6PedalFWD U16 10000	0.11 - Y6PedalFWD U16 10000	0.11 - X6PedalREV U16 10000	0.11 - Y6PedalREV U16 10000

Sauer-Danfoss CG150 #0 (Channel 0) 250k

Down PSI Pot Parameters Screen

PLUS+1 GUIDE Service Tool 5.0 (Not released for production) - [C:\CUSTOMERS\Gelfs Mfg\SA-4391 MIGHTY SWEEP\Programs\SERVICE TOOL\SA439151102MC50.P10]

File View Design Log Parameter Communication Options Tools Help

Diagnostic Navigator


Name	Value	Status
New System		
Documents		
ECU List		
SA433MC102		
SA433DP250102		
Log Functions		
MAIN		
JOY/PED/POT		
FAULTS		
BROOM		
Parameter Functions		
DEFAULTS		
ENGINE RPM		
PROPEL		
JOYSTICK		
FOOT PEDAL		
DOWN PSI POT		
SENSORS		

Graphical Overview

0.11 - DownPsiPotMaxHi U16 4700	0.11 - DownPsiPotMaxCal U16 4523	0.11 - DownPsiPwmFreq U16 200
0.11 - DownPsiPotMaxLow U16 4000		0.11 - BroomDrPsiMax U16 1440
0.11 - DownPsiPotMinHi U16 1000		0.11 - BroomDrPsiMin U16 0
0.11 - DownPsiPotMinLow U16 300	0.11 - DownPsiPotMinCal U16 443	


Sauer-Danfoss CG150 #0 (Channel 0) 250k

Sensors Parameters Screen




Hydraulic System				
ITEM NO.	PART NO.	DESCRIPTION	NO. REQ.	REMARKS
2	80838	Pressure Filler Breather	1	
2	80286	Filter, Return, SAE	1	Complete
	80286A	Filter Element, Spin-on	1	
51	B81925	Valve, Push-Pull, Steering , Cutoff, Tow Packag	1	optional
51	B80816	Hydraulic Cylinder, Steering	1	
52	B80817	Hydraulic Cylinder, Lift	1	
53	B80818	Hydraulic Cylinder, Swing	1	
54	80819	Hydraulic Oil Cooler	1	
56	B80993	Adapter, Housing, Bell	1	
57	B81896	Hydrostatic Pump, Linde	1	
58	B81897-3	Hydraulic Propel Motor	1	
59	B81898	Hydraulic Pump, Accessory, 28 GPM	1	
60	B81899	Steering Orbital Motor	1	
61	B80815	Hydraulic Motor, Broom Drive	1	
62	B81907	Hydraulic Control Manifold	1	
	B81955	Filter, Hydraulic Transmission, Spin-on	1	
	B81962-1	Transducer, Pressure, 580 PSI	1	
	B81962-2	Transducer, Pressure, 7250 PSI	1	
	B81962-3	Transducer, Pressure, 3626 PSI	2	
	B81942	Hose, 3/4", 6000 PSI, JIC Straight Swivels	2	
	B81993	Plug, Hex, O-ring, 32	1	
	B81995	Fitting, Hyd, Elbow, 12 JIC-20 O-ring	2	

Hydraulic Control Manifold




Seat, Console, Lights & Misc.



Hydraulic Control Manifold				
ITEM NO.	PART NO.	DESCRIPTION	NO. REQ.	REMARKS
	B81907	Hydraulic Control Manifold	1	Complete
1	B81907-1	Manifold Valve Body	1	
2	B81907-6	Valve, Relief, 250-3000 psi	1	
3	B81907-7	Valve, Priority	1	
4	B81907-8	Valve, Solenoid, Poppet	1	
5	B81907-9	Valve, Relief, 250-1800 psi	1	
6	B81907-10	Valve, Flow Control, 2.5 GPM	1	
7	B81907-3	Valve, Cartridge, Tandem Spool	1	
8	B81907-12	Valve, check, 30 psi	3	
9	B81907-11	Valve, Solenoid, 3 Position, 4 way, Open Center	1	
10	B81907-13	Plug, SAE-06	3	
11	B81907-15	Coil, 12 VDC, Duetsch, Broom On/Off	2	
12	B81907-20	Valve, Proportional, Relief, Float	1	
13	B81907-5	Valve, Piston, Dual	1	
14	B81907-14	Coil, 12VDC, Duetsch, Up/Dn & Swing	4	
15	B81907-16	Valve, Check, 5 psi	2	
16	B81907-21	Piston, Single Pilot	1	
17	B81907-18	Valve, Flow Control, Pressure Compensated	1	
18	B81907-22	Spacer, Coil, Size 8	2	
19	B81907-23	Plug, SAE-08	3	
20	B81907-24	Plug, SAE-04	1	
21	B81907-2	Plug, SAE-02	12	
22	B81907-4	Plug, Expansion	7	

Seat, Console, Lights & Misc.


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ.	REMARKS
1	B81103-1	Switch, Wiper, Variable Speed	1	
2	81535	Switch, Toggle, ON/OFF	6	
3	B81031	Switch, Ignition	1	
4	B81032	Switch, Light, Head	1	
5	80022	Steering Wheel	1	
6	80195	Switch , Turn Signal	1	
7	B80959	Steering Column with Tilt & Telescoping	1	
8	B81798	Joystick, Broom Function	1	
9	B81906	Joystick, Broom Fwd/Rev, Throttle	1	
10	B81962-6	Potentiometer, Float	1	
11	B81964	Controller, Broom	1	
5A	B81018	Cap, Steering Wheel	1	
	B60453	Cab Floor Weld	1	
	80020	Seat with Arm Rest	1	
	B81017	Seat Belt	1	
	B60425	Seat Stand	1	
	B60391	Control Panel Weld	1	
	80270	Steering Wheel Nut	1	
	B60449	Console, Weldment	1	
	B60450	Console Cover Weldment	1	
	B60522	Console Weld with Tack only	1	
	B60525	Console Weld with Tack only Tilt/Telescoping	1	
	B60526	Console Weld with Tack and Speed Tilt/Tel	1	
	B60527	Console Cover Weld for Tilt & Telescoping	1	
	B81911	Pin, Size 16	4	
	B81913	Pin, Size 12	2	
	B81916	Receptacle, Connector,Shell Size 24	1	
	B81959	Harness, Broom, Propulsion & Functions	1	
	B81962-7	Knob, Potentiometer	1	
	B81963	Pedal, Foot, Throttle, Optional	1	



Cab, Roll Bar & Accessories

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ.	REMARKS
	81214	Relay, Back-up Alarm	1	
	80197-1	Relay, Flasher, Turn Signal	1	
7	B81026	Horn, 12 volt	1	
8	B81018	Cap, Horn, Steering, Wheel	1	
9	B81027	Relay, Horn	1	
	B81032	Switch, Light, Head	1	
	B81025	Switch, Stop Light	1	
	B80978	Light, Dome, Large	1	
	B80998	Light, Rear, Brake/Turn/Tail	2	
	B80999	Light, Front, Turn Signal	2	
	B81000	Light, Head	2	
	B81130	Light, Park Brake, Indicator, Red	1	
	B81901	Lighter, Accessory Socket	1	
	80268	Light, Strobe	1	
	80198	Light, Work	1	
	B81990	Radio, AM/FM, Clock, Roof Mount	1	
	B81798	Joystick, Broom Function	1	
	B81906	Joystick, Broom Fwd/Rev, Throttle	1	
	B81960	Display	1	
	B81103-1	Switch, Wiper, Variable Speed	1	
	B82000	Switch, Door, Jam	2	
	B81131	Switch, Wiper, Std	1	
	B50011	Mat, Floor, Cab	1	
	B50012	Liner, Cab, Front	1	
	B50013	Liner, Cab, Rear	1	
	B50014	Liner, Cab, Head	1	
	B50015	Liner, Compartmetn	1	
	B80904	Lights, Rear, Brake/Turn/Tail, LED	2	
	B81086	Switch, Brake, Park	1	
	B81292	Diode, Brake	1	
	B81901	Outlet, Accessory, Lighter	1	
	B82012	Light, Head, LED	2	


Cab, Roll Bar & Accessories (Cont.)



Cab, Roll Bar & Accessories (Cont.)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ.	REMARKS
1	B60451	Cab Weld	1	Complete
2	80268	Strobe Light	1	
3	B81102	Wiper Motor, Front and Rear	1 ea	
4	B81100	Wiper Arm, Front and Rear	1 ea	
5	B81101	Wiper Blade, Front and Rear	1 ea	
7	B80992	AC Filter Element	1	
9	B60427	AC Filter Frame	1	
10	B81021	Door Stop Plunger	2	
11	B81022	Door Stop Socket	2	
12	B80987	Heating and Air Conditioning Unit, R134A	1	
13	B51188	Swing Arm Access Plate	1	
14	15087	Cap Screw, 5/16 X 1/2"	4	
15	B60502	Filter Element	1	
16	B60605	Pressurizing Blower	1	
17	B51442	Access Cover Plate	1	
	B60426	R.O.P.S. Roll Bar	1	
	B51099	Roll Bar Mount	2	
	15089	Cap Screw, 5/8 X 2" UNC Grade 5	8	
	15090	Cap Screw, 5/8 x 2 1/4" UNC Grade 5	4	
	15024	Nylock Hex Nut, 5/8"	12	
	15088	Flat Washer, 5/8	24	
	15086	5/16" Nylock Hex Nut	6	
	B81099	Wiper Washer, Front and Rear	1 ea	
	B81191	Washer Nozzle, Front and Rear	1 ea	
	B81192	Washer Bulkhead Fitting, Front and Rear	1 ea	
	B81193	Washer Hose Kit, Front and Rear	1 ea	
	B51122	Cab Rear Brace	1	
	B81102-2	Harness, CW to Park		
	B81102-3	Harness, CCW to Park		
	B81102A	Motor, Wiper, 2 Speed		
	B81989	Washer, Windshield, Dual Pump, 4 liter	1	
	B81992	Harness, Twelve Lead, With Fuse Box	1	
	B81994	Insulation, Cab, Floor	1	


WINDOW GLASS



WINDOW GLASS

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ.	REMARKS
1	B80833	Window, Glass, Front, Tinted, Safety	1	
2	B80834	Window, Glass, Rear, Tinted, Safety	1	
3	B80836	Window, Glass, Right-hand, Tinted, Safety	1	
4	B80837	Window, Glass, Left-hand, Tinted, Safety	1	
5	B81367	Window, Glass, Door, Lower, Tinted, Safety	2	
6	B81368	Window, Glass, Door, Upper, Tinted, Safety	2	
7	16147	Weather Strip, Glass,	111.8	Feet


RIGHT HAND DOOR ASSEMBLY



RIGHT HAND DOOR, ASSY B60387

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ.	REMARKS
1	15003	Nut, Hex, 1/4-20, GR 8, Y-Zn-PLD	2	
2	15004	Washer, Lock, 1/4, GR 8, Y-Zn-PLD	6	
3	15049	Screw, Cap, Hex, 1/4-20 x 1, GR 8, Y-Zn-PLD	4	
4	15064	Washer, Lock, 3/8, GR 8, Y-Zn-PLD	4	
5	15065	Nut, Hex, 3/8-16, GR 8, Y-Zn-PLD	2	
6	15131-SAE	Washer, Flat, SAE, 3/8, GR 8, Y-Zn-PLD	4	
7	15152	Screw, Cap, Hex, 3/8-16 x 3, GR 8, Y-Zn-PLD	2	
8	15158	Screw, Cap, Hex, 1/4-20 x 1 3/4, GR 8 Y-Zn-PLD	2	
9	15165	Washer, Flat, USS, 1/4, GR8, Y-Zn-PLD	2	
10	15202-SAE	Washer, Flat, SAE, 1/4, GR9, Y-Zn-PLD	8	
11	15260	Screw, Mach, 10-32 x 1/2, FLH, PHH, Zn-PLD	2	
	16146	Weather Stripping, Door		
12	16147LBD	Molding, Door, Broom, Lower	1	
13	16147UBD	Molding, Door, Broom, Upper	1	
14	B50008	Spacer, Door,Broom, Lower	1	
15	B50010	Cover, Latch, Door, Cab	1	
16	B60045	Assy, Seal, Air, Latch, Door	1	
17	B60387	Right Hand Door	1	
18	B80788	Handle, Outside, Locking, Keyed	2	
19	B80789	Handle, Inside	2	
20	B81021	Plunger, Door Holder	2	
21	B81367	Window, Door, Cab, Lower	2	
22	B81368	Window, Door, Cab, Upper	2	
23	B81370	Right Hand Rotor Latch	1	
24	B81369	Left Hand Rotor Latch	1	
25	B81371	Pin, Striker, Latch	2	
26	B81022	Socket, Door Holder	2	
27	B60388	Left Hand Door	1	


LEFT HAND DOOR ASSEMBLY



LEFTHAND DOOR ASSY B60388

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ.	REMARKS
1	15003	Nut, Hex, 1/4-20, GR 8, Y-Zn-PLD	2	
2	15004	Washer, Lock, 1/4, GR 8, Y-Zn-PLD	6	
3	15049	Screw, Cap, Hex, 1/4-20 x 1, GR 8, Y-Zn-PLD	4	
4	15064	Washer, Lock, 3/8, GR 8, Y-Zn-PLD	4	
5	15065	Nut, Hex, 3/8-16, GR 8, Y-Zn-PLD	2	
6	15131-SAE	Washer, Flat, SAE, 3/8, GR 8, Y-Zn-PLD	4	
7	15152	Screw, Cap, Hex, 3/8-16 x 3, GR 8, Y-Zn-PLD	2	
8	15158	Screw, Cap, Hex, 1/4-20 x 1 3/4, GR 8 Y-Zn-PLD	2	
9	15165	Washer, Flat, USS, 1/4, GR8, Y-Zn-PLD	2	
10	15202-SAE	Washer, Flat, SAE, 1/4, GR9, Y-Zn-PLD	8	
11	15260	Screw, Mach, 10-32 x 1/2, FLH, PHH, Zn-PLD	2	
12	16147LBD	Molding, Door, Broom, Lower	1	
13	16147UBD	Molding, Door, Broom, Upper	1	
14	B50008	Spacer, Door,Broom, Lower	1	
15	B50010	Cover, Latch, Door, Cab	1	
16	B60045	Assy, Seal, Air, Latch, Door	1	
17	B60387	Right Hand Door	1	
18	B80788	Handle, Outside, Locking, Keyed	2	
19	B80789	Handle, Inside	2	
20	B81021	Plunger, Door Holder	2	
21	B81367	Window, Door, Cab, Lower	2	
22	B81368	Window, Door, Cab, Upper	2	
23	B81370	Right Hand Rotor Latch	1	
24	B81369	Left Hand Rotor Latch	1	
25	B81371	Pin, Striker, Latch	2	
26	B81022	Socket, Door Holder	2	
27	B60388	Left Hand Door	1	


Air Conditioning



Air Conditioning System


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ.	REMARKS
3	B80988	Condenser	1	
8	B60577	Assy, Hose, AC, AC Unit to Compressor, #10	1	
9	B60578	Assy, Hose, AC, Compressor to Condensor, #8	1	
10	B60575	Assy, Hose, Ac, Condensor to Dryer, #6	1	
11	B60576	Assy, Hose, Ac, Dryer to AC Unit, #6	1	
	B80985	Moisture & Sight Glass	1	
	B80986	Switch, Binary, Low Pressure	1	
	B80987	Ac/Heater Unit	1	
	B80989	AC Dryer	1	
	B80990	AC Dryer Mount	1	
	B80992	Filter, Ac, Pre-Filter	1	Replacement
	B81904-1	Compressor	1	
	B81900-17	Compressor V-belt	1	
	B80987-4	Filter, AC, Foam, 3" Interior		Replacement
	B80987-1	Valve, Heater, Control		Replacement
	B80987-2	Cable, Heater Control		Replacement
	B80987-3	Switch, Fan Speed, Control		Replacement
	B80987-5	Core, Heater		Replacement
	B80987-6	Evaporator Core		Replacement
	B80987-7	Assy, Blower, Fan		Replacement
	B81926	Fitting, Elbow, 90 Degree, R-134a High port #8		


Water System



Water System				
ITEM NO.	PART NO.	DESCRIPTION	NO. REQ.	REMARKS
26	B51161	Spray Bracket	2	
2	B60456	Top Tank Holddown	1	
21	B60616-1	Assy, Box, Control, Water, Tanks Holddown	1	
10	B81104	Water Pump	1	
8	B81106	Clamp, Hose, 1/2"	29	
11	B81107	Fitting, TEE, Barb	1	
12	B81108	Fitting, Elbow, Nozzle, Spray	4	
13	B81109	Fitting, TEE, Nozzle, Spray	4	
14	B81110	Fitting, Cross, Nozzle, Spray	2	
15	B81111	Stainer, TEE, Line	1	
9	B81112	Cap, Nozzle, Spray	10	
17	B81113	Strainer, 100 Mesh, Spray, Tip	10	
18	B81114	Tip, Spray, Brass	10	
22	B81116	Adjustable Valve	1	
9	B81117	Tubing, Clear, 1/2"	30.72	Feet
21	B81118	Fitting, Elbow, 1/2" MPT x 1/2" Barbed	2	
4	B81119	Fitting, Nipple, Close, 3/4" NPT	2	
5	B81120	1 1/2" Male Pipe Plug	1	
6	B81121	Fitting, Elbow, Street, 3/4" NPT	1	
3	B81122	Valve, Union	1	
7	B81123	Fitting, 3/4" NPT X 1/2" Barbed	4	
19	B81124	Fitting, Nipple, Reducing, 1/2" x 3/8" NPT	1	
1	B81125	Poly Tank 150 gallons	1	
24	B81195	Nylon Nut (Included with #12, 13 & 14)	10	
19	B81973	Coupler, 1/2" NPT	1	
20	B81975	Fitting, TEE, 3/4" NPT	1	
7	B81976	Fitting, 3/8" NPT X 1/2 Barbed	1	
	B81998	Fitting, Reducing, 3/4" x 1/2"	1	
	B81999	Valve, Boiler, 3/4"	1	
	B51207	Cushion, Tank, Rubber	2	


CAB PRESSURIZER





CAB PRESSURIZER


ITEM NO.	PART NO.			REMARKS
0	B60506	Pressurizer, Cab	1	COMPLETE
1	15085	Nut, Hex, Nylock, 1/4-20 GR 8 Y-Zn-PLD	2	
2	15149	Bolt, Elevator, 1/2-20 X 3/4, PL-FNSH	2	
3	15165	Washer, Flat, 1/4. GR 8, Y-Zn-PLD	2	
4	15278	Screw, Hex, WSH, TEK, 1/4 X 1, ZN-PLD	4	
5	B51105	Bracket, Filter, Cab Pressurizer	1	
6	B51482	Seat, Filter, Cab Pressurizer	1	
7	B60502	Assy, Filter, Cab Pressurizer	1	
8	B60503	Assy, Wire, Switch to Fan	1	
9	B60504	Assy, Wire, Power	1	
10	B60505	Assy, Blower, Light, Cab	1	
11	B80963	Fuse, 20 AMP, IN-LINE	1	
12	81535	Switch, Toggle, SPST	1	
13	B80965	Louver, Pressurizer	2	
14	B80966	Switch, Rheostat	1	
15	B80967	Knob, Control	1	
16	B80968	Latch, Filter Pan	2	
17	B80969	Console, Sub, Assy	1	
18	B80978	Light, Dome, Small	1	
19	B80979	Assy, Blower, Pressurizer, Cab	1	
20	B80980	Assy, Holder, Fuse	1	
21	B81162	Pan, Filter	1	



ENGINE

ITEM NO.	PART NO.			REMARKS
	B81900	Engine, John Deere 4045TF285, 85 HP	1	COMPLETE
1	81278	Hose, Hump, 3"	1	
2	82731	Hose, Hump, Reducing, 4-1/2" to 4"	1	
3	B81996	Elbow, Rubber, Reducing, 4"-3"	1	
4	82734	Clamp, T-bolt, 3"	7	
5	82735	Clamp, T-bolt, 4"	2	
6	82748	Clamp, T-bolt, 5"	1	
8	B51254	Tube, Exhaust, 3" X 44"	1	
9	B51753	Tube, Exhaust, 3" X 7"	2	
10	B80996	Elbow, Rubber, Intake, 3"	2	
10	B51759	Elbow, Exhaust, 3" with 12" Leg- Modified	1	
11	B80902	Pre-Cleaner, Turbo II, With Clamp	1	
13	B81774	Clamp, TBG, U-bolt, 3"	2	
14	82732	Hose, Reducing, Insert, 4" to 3"	1	


John Deere 4045TF 85 HP RIGHTSIDE



ENGINE RIGHTSIDE

ITEM NO.	PART NO.			REMARKS
	B81900	Engine, John Deere 4045TF285, 85 HP	1	COMPLETE
1	B81900-15	Filter, Air, Secondary	1	
2	B81900-16	Filter, Air, Primary	1	
3	B81900-19	Muffler	1	
4	B81900-12	Filter, Fuel, Final, Fuel/Water Separator	1	
5	B81900-21	Filter, Oil	1	
6	B81900-75	Alternator, John Deere, 75 Amp	1	
7	B81900-17	Belt, Serpentine, 91.5" x 1.121"	1	
8	B81900-11	Starter, John Deere, 4045TF285, 85 HP	1	
	B81900-13	Filter, Fuel, Primary, Fuel/Water Separator	1	Not Shown
	B80824	Isolator, Rubber, Engine	4	Not Shown
	B81952	Hose, Heater, 5/8"	85"	Not Shown
	81223	Clamp, Hose, 5/8"	4	Not Shown
	80316	Clamp, Cushion, 1/2"	1	Not Shown
	81603	Clamp, Cushion, 1-1/2", Fuel Hose	1	Not Shown
	B82008	Tube, Overflow, 5/16"	52"	Not Shown
	B81955	Filter, Hydraulic Transmission, Spin-on	1	Not Shown

ENGINE LEFTSIDE



ENGINE LEFTSIDE

ITEM NO.	PART NO.			REMARKS
1	B81900 B81904-1	Engine, John Deere 4045TF285, 85 HP AC Compressor	1 1	COMPLETE

ISO 32
HYD. OIL

DIESEL FUEL

CAUTION
DOT 3 BRAKE
FLUID ONLY

DANGER
CRUSH ZONE
KEEP CLEAR
(SEVERE DAMAGE)


MODEL: _____
SERIAL NO. _____
GEFFS MANUFACTURING, INC.
POCATELLO, IDAHO

BROOM FLOAT STROBE LIGHT WATER SYSTEM BACK LIGHT

2003-8 KO

MIGHTY SWEEP

LOW CHANGE LOW LOW HIGH GLOW PARK
WATER AIR OIL HYD HYD PLUG BRAKE
FILTER PRESS OIL TEMP



WARNING

USE SEAT BELT

WARNING

THIS STRUCTURE'S PROTECTIVE
CAPABILITY MAY BE IMPAIRED
BY STRUCTURAL DAMAGE,
OVERTURN, OR ALTERATION.
IF ANY OF THESE CONDITIONS
OCCUR, THIS STRUCTURE MUST
BE REPLACED.

IMPORTANT

LATCH THE DOOR CLOSED
DURING TRANSPORTATION


Decal KIT B60489-12

ITEM NO.	PART NO.		REMARKS
1	80087	Decal , ISO 32 HYD OIL	1
2	80088	Decal, DIESEL FUEL	2
3	80318	Decal, CAUTION BRAKE FLUID	1
4	80455	Decal , CAUTION CRUSH ZONE	2
5	80461	Template SERIAL NUMBER & MODEL	1
6	80545	Decal , SMALL GEFFS LOGO	2
7	B50029	Template, CONSOLE RIGHTHAND	1
8	B80945	Decal, BROOM LIGHTS	1
9	B80949	Decal, 2003-8KO	2
10	B80950	Decal, MIGHTY SWEEP	2
11	B80952	Decal, BROOM LARGE STRIPE	2
12	B80956	Decal, WARNING STRUCTURES	2
13	B80957	Decal, WARNING SEAT BELT	1
14	B81198	Decal , BROOM SWITCH	1
15	B81326	Decal , DOOR LATCH	2
16	B81329	Decal FUEL GAUGE	1

Section 12


Schematics

Hydraulic Schematic - - - - -	Page 2
Hydraulic Schematic Hoses - - - - -	Page 4
Hydraulic Schematic Hoses Cont' - - - - -	Page 6
Hydraulic Schematic Fittings - - - - -	Page 8
Electrical Schematic - - - - -	Page 10




Hydraulic Schematic Components

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ.	REMARKS
1	B81898	Hydraulic Pump	1	
2	B81899	Motor, Orbital, Motor	1	
3	B80816	Steering Cylinder	1	
4	B80818	Swing Cylinder	1	
5	B80817	Lift Cylinder	1	
6	B81907	Manifold Valve Assembly Complete	1	See Page 10
	B81907-1	Manifold	1	Sub Item 1
	B81907-2	Plug, SAE-02	12	Sub Item 21
	B81907-3	Valve, Cartridge	1	Sub Item 9
	B81907-4	Plug, Expansion	7	Sub Item 22
	B81907-5	Valve, Piston, Dual	1	Sub Item 13
	B81907-6	Valve, Relief, 250-3000 psi	1	Sub Item 2
	B81907-7	Valve, Priority	1	Sub Item 3
	B81907-8	Valve, Solenoid, Poppet	1	Sub Item 4
	B81907-9	Valve, Relief, 250-1800 psi	1	Sub Item 5
	B81907-10	Valve, Flow Control, 2.5 GPM	1	Sub Item 6
	B81907-11	Valve, Solenoid, 3 Position, 4 way	1	Sub Item 7
	B81907-12	Valve, check, 30 psi	3	Sub Item 8
	B81907-13	Plug, SAE-06	3	Sub Item 10
	B81907-14	Coil, 12VDC, Duetsch, Up/Dn & Swing	4	Sub Item 14
	B81907-15	Coil, 12 VDC, Duetsch, Broom On/Off	2	Sub Item 11
	B81907-16	Valve, Check, 5 psi	2	Sub Item 15
	B81907-18	Valve, Flow Control, Pressure Compensated	1	Sub Item 17
	B81907-20	Valve, Proportional, Relief, Float	1	Sub Item 12
	B81907-21	Piston, Single Pilot	1	Sub Item 16
	B81907-22	Spacer, Coil, Size 8	2	Sub Item 18
	B81907-23	Plug, SAE-08	3	Sub Item 19
	B81907-24	Plug, SAE-04	1	Sub Item 20
7	B81903	Motor, Broom Hydraulic Motor	1	
8	B80805	Filter Assembly	1	
9	B80819	Oil Cooler	1	
10	50344	Return Manifold	1	
11	B81896	Hydrostatic Transmission	1	
12	B81898	Pump, Hydr, Auxiliary	1	
13	82837	Strainer, Suction, 100 Mesh, O ring	2	
14	82838	Diffuser, Hydr, Return	1	
15	B81962-4	Sensor, Temperature	1	
16	B81962-1	Transducer, Pressure, 580 PSI	2	
17	B81962-2	Transducer, Pressure, 7250 PSI	1	
18	B81962-3	Transducer, Pressure, 3626 PSI	1	



Hydraulic Schematic Hoses

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ.	REMARKS
1	B60014	HOSE, ASSY, LEFT ORBITAL TO BULKHEAD	1	
2	B60015	HOSE, ASSY, RIGHT ORBITAL TO BULKHEAD	1	
3	B60016	HOSE, ASSY, RIGHT BULKHEAD TO STEER CYL	1	
4	B60017	HOSE, ASSY, LEFT BULKHEAD TO STEER CYL	1	
5	B60018	HOSE, ASSY, MAN. PORT S TO ORBIT PRESSURE	1	
6	B60019	HOSE, ASSY, ORBITAL TANK TO RETURN MAN.	1	
7	B60020	HOSE, ASSY, SWING CYLINDER TO A2 PORT	1	
8	B60021	HOSE, ASSY, SWING CYLINDER TO PORT A1	1	
9	B60022	HOSE, ASSY, LIFT CYLINDER TO PORT B1 & B2	2	
10	B60023	HOSE, ASSY, PORT M1 VALVE MAN. TO MOTOR	1	
11	B60024	HOSE, ASSY, BROOM DRIVE MOTOR TO RETURN	1	
12	B60025	HOSE, ASSY, CASE DRAIN DRIVE MOTOR TO TK	1	
13	B60026	HOSE, ASSY, CASE DRAIN PORT L DRIVE PUMP	1	
14	B60027	HOSE, ASSY, CASE DRAIN PORT T DRIVE PUMP	1	
15	B60028	HOSE, ASSY, HYDR TANK TO PORT B DRIVE PUMP	1	
16	B60029	HOSE, ASSY, PORT A TO PORT F ON DRIVE PUMP	1	
17	B60031	HOSE, ASSY, BROOM DRIVE MOTOR TO RETURN	1	
18	B60032	HOSE, ASSY, BROOM FILTER TO HEATEXCHANGER	1	
19	B60033	HOSE, ASSY, HEAT EXCHANGER- HYDR TANK	1	
20	B60034	AUXILIARY PUMP TO VALVE MANIFOLD	1	




Hydraulic Schematic Hoses Cont'				
ITEM NO.	PART NO.	DESCRIPTION	NO. REQ.	REMARKS
21	B60035	HDYR TANK TO AUXILIARY PUMP SUCTION	1	
22	B81942	HOSE, HYDR TRANS TO DRIVE PUMP	2	
23	B60012	HOSE, ASSY, STEERING BYPASS TOWING OPTION	1	
24	B60013	HOSE, ASSY, STEERING BYPASS TOWING OPTION	1	

9/2012

Revised

Geffs Manufacturing Inc.

Section 12, PAGE 7



Hydraulic Schematic Fittings







ITEM NO.	PART NO.	DESCRIPTION	NO. REQ.	REMARKS
1	80526	Hydraulic Fitting Straight JIC/NPT	2	2404-6-6
2	80686	Hydraulic Fitting 90° Elbow JIC/NPT	2	2501-6-6
3	80706	Hydraulic Fitting O-ring 90° Elbow	7	6801-6-6
4	80603	Hydraulic Fitting, Bulkhead	2	WI-7709
5	80694	Hydraulic Fitting O-Ring Straight JIC	6	6400-6-8
6	80693	Hydraulic Fitting O-Ring Straight JIC	2	6801-16-20
7	81614	Hydraulic Fitting O-ring 90° Elbow	1	6801-16-12
8	81482	Hydraulic Fitting O-ring 45° Elbow	1	6802-16-12
9	81315	Hydraulic Fitting O-ring 45° Elbow	1	6802-12-12
10	81301	Hydraulic Fitting O-Ring Straight JIC	3	6400-12-10
11	80705	Hydraulic Fitting O-ring 90° Elbow	3	6801-16-16
12	81303	Hydraulic Fitting O-ring 90° Elbow	1	6801-20-20
13	81615	Hydraulic Fitting O-ring Swivel Female JIC	1	6402-12-16
14	81334	Hydraulic Fitting O-Ring Straight JIC	2	6400-16-20
15	B81950	Hydraulic Fitting Split Flange SAE 62	4	SFK-62-12
16	B81951	Hydraulic Fitting 90° Elbow SAE 62	4	1704-62-12-12
17	B81995	Hydraulic Fitting O-ring 90° Elbow	1	6801-12-20
18	80639	Hydraulic Fitting O-ring 90° Elbow	1	6801-16-20
19	80621	Hydraulic Fitting O-ring 45° Elbow	1	6802-20-20
20	81248	Hydraulic Fitting O-ring 90° Elbow	3	6801-12-12
23	80701	Hydraulic Fitting Branching TEE – Tow Opt	1	6602-6-6
24	80722	Hydraulic Fitting 90° Elbow JIC/NPT – Tow Opt	1	2501-6-8
25	80628	Hydraulic Fitting 90° Elbow Swivel JIC- Tow Opt	1	6500-06
26	81331	Hydraulic Fitting Straight JIC/NPT – Tow Opt	2	2404-6-8
27	80742	Hydraulic Fitting Plug, Hex – Tow Opt	1	3152-6
28	B81979	Hydraulic Fitting, Adapter, Transducer, Return	1	6410-12-06
29	B81978	Hydraulic Fitting, Adapter, Transducer, Pump	2	M-FB-6410- 14x1.5-06WO
30	81493	Hydraulic Fitting O-ring 45° Elbow	2	6802-06-06
31				
32				
33				

JOHN DEERE ENGINE SCHEMATIC

13 PAGES

4.5L 12V ECU Wiring Diagram 1

J01
ECU Harness Connector
(Black Face)




4.5 Liter 12 Volt ECU Wiring Diagram 1 (PTE)

RG15052A—UN—06OCT08

A—Female Socket	J1-A4—[5445 Dark Green] Pump Position Pulse	J1-E4—[5443 Orange] Pump Position Return	J1-H2—[5419 White] HP Pump Suction Control Valve
B—Male Pin			
C—Shield (Not On Rear Mount ECU)	J1-B4—[5447 Purple] Crank Position Pulse	J1-F1—[5498 Gray] Injector #3 Inject Pulse	Low Drive X01—Crank Position Sensor
D—Twisted Pair	J1-C1—[5499 White] Injector #2 Inject Pulse	J1-F2—[5410A Black] Wiring Shield	X02—Pump Position Sensor Y01—Suction Control Valve
C01—Fuel Injector Connector			
J01—ECU Harness Connector (Black Face)	J1-D1—[5495 Dark Green] Injector #4 Inject Pulse	J1-G1—[5491 Brown] Injector #1 & #4 Power	
	J1-D4—[5448 Gray] Crank Position Return	J1-G2—[5496 Light Blue] Injector #2 & #3 Power	
	J1-E1—[5493 Orange] Injector #1 Inject Pulse	J1-H1—[5424 Yellow] HP Pump Suction Control Valve	
			High Drive


4.5L 12V ECU Wiring Diagram 2



4.5 Liter 12 Volt ECU Wiring Diagram 2 (PTE)

A—Female Socket	J1-B3—[5469 White] Fuel Pressure Signal	J1-E3—[5475 Dark Green] Fuel Rail Pressure Signal	P05—Fuel Rail Pressure Sensor
B—Male Pin	J1-C2—[5463 Orange] Intake Manifold Air Temperature	J1-F3—[5416A Light Blue] 5 Volt Power Supply #2B Positive	T02—Intake Manifold Air Temperature Sensor
D01—Water In Fuel Sensor	J1-C4—[5461 Brown] Coolant Temperature Signal	J1-F4—[5428 Gray] Fuel Temperature Signal	T04—Coolant Temperature Sensor
J01—ECU Harness Connector (Black Face)	J1-D2—[5414A Yellow] 5 Volt Power Supply #2B Return	P03—Low Pressure Fuel Sensor (If Equipped)	T05—Fuel Temperature Sensor
J1-A3—[5467 Purple] Engine Oil Pressure Signal	J1-D3—[5946 Lt Blue] 5 Volt Power Supply #1 Positive	P03A—Low Pressure Fuel Sensor Interconnect	
J1-B2—[5453 Orange] Water In Fuel Signal	J1-E2—[5427 Orange] 5 Volt Power Supply #1 Return	P04—Engine Oil Pressure Sensor	


4.5L 12V ECU Wiring Diagram 3



4.5 Liter 12 Volt ECU Wiring Diagram 3 (PTE)

A—See Diagram (6)	L—Chassis Ground	C10—CAN Terminator	J2-B1—[5905A Dark Green] CAN
B—Alternator Excitation	M—Fuse (10 Amp)	C11—Diagnostic Connector	Low
C—Male Pin	N—Fuel Heater Relay (If Equipped)	C12—Transient Voltage Protection (TVP)	J2-B2—[5012A Red] Ignition Key Start/Run Switch
D—Female Socket	O—Solenoid B+	C13—Starter Relay Coil Return	J2-K2—[5020A Black] CAN Shield
E—120 Ω Resistor	P—Starter Relay	C14—Starter Relay Coil Control	J2-L1—[5022A Red] Battery Positive
F—See Diagram (5)	Q—Starter Solenoid 'S' Terminal	C15—Remote Switch	
G—Twisted Pair	R—Single Point Ground	C18—Fuel Heater Option	J2-L2—[5050A Black] Battery Negative
H—Shield	B1—12 Volt	F01—30 Amp	J2-L3—[5050B Black] Battery Negative
I—See Diagram (4,5)	C02—Accessory Connector A	F02—20 Amp	
J—Fuel Heater (If Equipped)	C07—Accessory Connector B	J02—ECU Harness Connector (Red Face)	J2-L4—[5022B Red] Battery Positive
K—Original Connection. See Instruction for Update	C09—Control Panel Connector	J2-A1—[5904A Yellow] CAN High	J2-M1—[5022C Red] Battery Positive
			J2-M2—[5050C Black] Battery Negative
			J2-M4—[5022D Red] Battery Positive
			VBatt—Battery Positive

4.5L 12V ECU Wiring Diagram 4




4.5 Liter 12 Volt ECU Wiring Diagram 4 (PTE)

RG15065A - JUN - 06OCT08

A—Loss of Coolant Switch	J—23 Pin Connector (Auxiliary Connector)	J02— ECU Harness Connector (Red Face)	J2-G3—[5714A Yellow] 5 Volt Power Supply #2A
B—Female Socket	K—Remote Cruise Switch	J2-B2—[5012A Red] Ignition Key	Negative
C—Air Filter Restriction Switch	L—Stop Engine Lamp	J2-B3—[5917 Purple] Remote Start/Run Switch	J2-G4—[5948 Gray] Low Coolant Level Switch
D—External Shutdown Switch	M—See Diagram (3.5)	N—Cruise Brake Switch	J2-H4—[5937 Purple] Droop/Isochronous Governor Switch
E—Male Pin	O—Secondary Analog Throttle	P—Single Point Ground	J2-J1—[5939 White] External Derate Switch
F—External Derate Switch	Q—Drop/Isoc (Isochronous) Governor Switch	C08— Auxiliary Connector	J2-J2—[5971 Brown] Cruise Cancel/Resume Switch
G—Cruise Cancell/Resume Switch			J2-K1—[5941 Brown] External Shutdown Switch
H—See Diagram (5)			
I— Cruise On Switch			
		J2-E1—[5943 Orange] Cruise Brake Switch	
		J2-F2—[5954 Yellow] Cruise On/Off Switch	
		J2-F3—[5913 Orange] Secondary Analog Throttle Signal	
		J2-G2—[5911 Brown] 5 Volt Power Supply #2A Positive	

4.5L 12V ECU Wiring Diagram 5




RG15056A —UN—09OC708

A—Resume Coast/Bump Down Switch	K—Accessory	U—Tachometer	J2-C3—[5814 Yellow] 5 Volt Power Supply #3 Negative
B—Female Socket	L—Run	V—Control Panel	J2-D1—[5439 White] Tachometer Pulse Output
C—Set Accel/Bump Up Switch	M—See Diagram (3,4)	C09—Control Panel Connector	J2-D4—[5955 Dark Green] Set/Accel/Bump Up Switch
D—Male Pin	N—Warning Lamp	J02—ECU Harness Connector (Red Face)	J2-E3—[5913 Orange] Secondary Analog Throttle Signal
E—Bump Enable Switch	O—Wait to Start Lamp	J2-A3—[5616 Light Blue] 5 Volt Power Supply #3 Positive	J2-E4—[5923 Orange] Bump Enable Switch
F—Key Switch	P—Primary Analog Throttle	J2-A4—[5915 Dark Green] Primary Analog Throttle Signal	J2-F1—[5936 Light Blue] Resume Coast/Bump Down Switch
G—21 Pin Connector (Panel Connector)	Q—Multi-State Throttle	J2-B2—[5012A Red] Ignition Key Start/Run Switch	J2-G3—[5714A Yellow] 5 Volt Power Supply #2A Negative
H—Battery	R—See Diagram (4)	J2-B4—[5947 Purple] Multistate Throttle Signal	
I—See Diagram (3)	S—Shutdown Override Switch	J2-C1—[5916 Light Blue] Warning Lamp Drive Return	
J—Start	T—Single Point Ground	J2-C2—[5474 Yellow] Wait To Start Lamp Drive Return	

A—Female Socket	E—Male Pin	C03—Air Heater Option	J1-H4—[5429 White] Air Heater
B—Air Heater Relay (If Equipped)	F—See Diagram (3)	C07—Accessory Connector B	Relay Control
C—Air Heater (If Equipped)	G—Single Point Ground	J01—ECU Harness Connector	VBatt—Battery Positive
D—Chassis Ground	C02—Accessory Connector A	(Black Face)	
		J1-A2—[5443 Orange] Air Heater	Relay Status

4.5L 12V ECU Wiring Diagram 7




4.5 Liter 12 Volt ECU Wiring Diagram 7 (PTE)


- | | | | |
|------------------------------------|--------------------------------------|---|--|
| A—(Type 2 Fuel System, Key Switch) | D—Male Pin | G—Low Pressure Fuel Pump Relay (If Equipped) | J02— ECU Harness Connector (Red Face) |
| B—Key Switch Run | E—Single Point Ground | C30— Low Pressure Fuel Pump Connector (If Equipped) | J2-M3—Low Pressure Fuel Pump Relay Drive |
| C—Female Socket | F—(Type 2 Fuel System, Relay Switch) | C32— Low Pressure Fuel Pump (If Equipped) | VBatt— Battery Positive |

RG150 50A —UN—06OCT08

CONTROLLER HARNESS SCHEMATICS

2 PAGES





BROOM HARNESS SCHEMATIC

2 PAGES

BROOM WIRING

AIR CONDITIONER/HEATER

A/C compressor to Binary switch
Binary Switch to A/C Unit Black # 902
Fuse Panel Black/white # 904 to A/C Power in
Ground to Common Ground
Brown Wire on A/C Not Used

FUSE BLOCK FLASHERS

Jump together

12 VOLT POWER OUTLET

Fuse Panel Orange # 959 wire to Center Post
Ground to common ground

DOME LIGHT

Fuse Panel White # 945 wire to Positive on Light
Use Dome Ground to connect all door switches and light to toggle on pressurizer

HEAD LIGHTS

Fuse panel Red/Black # 928 wire to Switch Power IN
Switch to Tail Lights Brown # 929 wire
Switch to Head Lights Tan # 909 wire

IGNITION SWITCH

Fuse panel Pink # 931 wire To Ignition
Fuse Panel Brown # 932 wire To ACC
Fuse Panel Orange # 933 wire To Ignition
Fuse Panel Red # 934 wire to B+
Purple # 919 wire Starter Solenoid to Start on ignition switch
Positive Lead from Pressurizer to Ignition
Positive Lead from Controller to Ignition

RADIO

Fuse Panel Red # 940 wire to Radio White wire Memory
Fuse Panel Red/Black # 941 wire to Radio Red Ignition wire
Black to Common Ground

DEFROST FAN

Fuse Panel Orange/Black #955 wire to Positive Defrost fan wire
Black to common Ground

EMERGENCY PARK BRAKE SWITCH

Red + with White Park Brake wire from display harness to console indicator light wire
Indicator light to brown # 951 wire on Water Spray pump toggle
Black to common ground

WORK LIGHT/ STROBE LIGHT

Fuse Panel Purple # 952 wire to Center of Work light and Strobe toggle switches
Strobe toggle switch to red wire
Work Light toggle switch to Light Green # 956 wire to Work Light
Black to common ground

WIPER SWITCHES

Tie together Yellow wire and White wire (High/Low) to Red on wiper harness
Blue wire to Yellow wire on wiper harness
Black to common ground
Red Wire to fuse panel Blue # 905 wire
Brown wire to washer motors (Brown/Black front, Brown/White Rear)
Green Wire on Wiper Motor Park

C09 ENGINE HARNESS

Red # 915 wire to "B" on plug Battery
Purple # 919 wire to "D" on plug Starter solenoid
Pink # 920 wire to "G" on plug Run
Red 12 volt wire from fuse block ACC to "J" on plug Accessory on engine harness

BATTERY

Red #915 wire to Positive terminal on starter

SPRAY BAR PUMP

Spray bar toggle switch Red wire to Spray bar pump
Ignition red wire to toggle switch
Black to common ground

HORN

Fuse panel Green # 924 Wire to Positive on Horn
Black to Common Ground

BRAKE SWITCH

C4 on Controller Harness power to one brake switch terminal
Turn Signal Switch White # 918 Wire/C4 Brake Pedal to Diode to Other Brake Switch
Diode power flows from switch

TURN SIGNAL SWITCH

Switch Yellow wire to L on Flasher
Switch Blue wire to P on Flasher
Black Jumper from fuse block to X on Flasher
Switch White wire to common ground
Switch Gray/Black wire to white # 918 wire
Switch Gray wire to Yellow # 949 wire to Left rear turn signal light
Switch Black wire to Green # 948 wire to Right rear turn signal light
Switch Green wire to Light Blue # 926 wire to Left front turn signal light
Switch Red wire to Blue # 925 wire to Right front turn signal light

Notes

